










genuine original spare parts



EN Check the alternating voltage at the pcb output with the tester.
FR Vérifier la tension alternative à la sortie de la carte avec le testeur.
IT Controllare la tensione alternata all'uscita schedacon il tester.

ES Verifique el voltaje alterno en la salida de la tarjeta electrónica con el probador.
DE Mit dem Tester die Wechselspannung am Elektronikplatinne prüfen.
NL Controleer de wisselspanning op de elektronische kaart met de tester.



65104558

61315654

