




Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2
	1PR120148	Filtre a air				
	1PR120148	Filtre a air				
1	1PR190827	Panneau	1			
2	1PR120145	Filtre a air	2			
3	HX0010211702	Capot	3			
4	1PR190790	Panneau	1			
5	1PR110309	Turbine	1			
6	1PR160799	Roulement	1			
7	1PR160578	Support	1			
8	1PR110377	Volet	1			
9	HX0010209723	Blocage axe	3			
10	HX0010209029	Volet	3			
11	1PR190814	Panneau	1			
12	1PR160204	Bouchon	1			
13	HX0010211698	Support	1			
14	HX0010206934	Tube condensats	1			
15	1PR160871	Support	1			
16	1PR160668	Support mural	1			
17	HX0010209030	Support	1			
18	HX0010207635	Support	1			
19	1PR150456	Evaporateur	1			
20	HX0010102525	Boitier electrique	1			
21	1PR160867	Capot	1			
22	1PR160866	Boitier electrique	1			

Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2
23	1PR031248	Carte electronique	1			
24	HX0010403863	Bornier électrique	1			
25	HX0010208734	Blocage axe	1			
26	1PR090083	Moteur volet	1			
27	1PR060575	Moteur ventilateur	1			
28	1PR160778	(B-C) Capot	1			
29	1PR160777	Capot	1			
30	1PR160772	Capot	1			
31	1PR160773	(B-C) Capot	1			
32	HX0010211703	Capot	1			
33	HX0010211167	Support	1			
34	HX0010211168	Support	1			
35	HX0010877304	Capot	1			
36	HX0010211048	(CNR) Boitier électrique	1			
37	1PR031243	Carte display	1			
38	1PR070411	Sonde temperature	1			
39	HX001A4600001	Pile	2			
40	7ACEL1758	Telecommande IR RC09	1			
41	HX001A1434039A	Tube condensats	1			
42	HX0010600367B	Vis	2			
43	HX001A1433307	Support	1			
44	HX0010211049	Boitier électrique	1			