




Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2
		Adaptateur contact sec ON/OFF				
		telecommande filaire RCW22				
1	1PR191076	Panneau	1			
2	1PR120004	Filtre air	2			
4	12122000006755	Capot	1			
5	12122000A65218	Panneau	1			
5.1	12122000009477	Cache vis	1			
6	12122000004587	Support	1			
8	1PR110007	Volet	1			
9	1PR150025	Evaporateur	1			
10	12122000005540	Capot	1			
11	1PR060130	Moteur ventilateur	1			
12	1PR160499	Support	1			
13	1PR160474	Roulement	1			
14	1PR110253	Turbine	1			
16	12122000A03079	Chassis	1			
16.1	1PR060612	Moteur volet	1			
16.1	1PR090011	Moteur volet	1			
16.3	12122000009455	Volet	1			
16.4	12122000010098	Support	1			
17	12122000012943	Support	1			
18	1PR160004	Support mural	1			
19	1PR031534	Carte electronique ens	1			
19.1	12122000004577	Boitier electrique	1			

Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2
19.2	12122000004639	Boitier electrique	1			
19.3	12122000004632	Boitier electrique	1			
19.4	17122000A35521	Carte electronique	1			
19.5	1PR070492	Sonde temperature	1			
19.6	1PR070491	Sonde temperature	1			
19.7	17400401000094	(CNR)Bornier electrique	1			
20	12122000005020	Capot	1			
21	7ACEL1740	Telecommande IR RC08C AW	1			
22	12600701000039	(CNR)Joint	1			
23	1PR160106	Raccord	1			
28	1PR160464	Raccord	1		90#	
40	1PR120038	Filtre	1			
40	1PR120239	Filtre a air	1			
42	15500209000001	Vanne detection fuite	1			
43	1PR120228	Filtre ionizer	1			
45	1PR160670	Support telecommande RC08	1			
46	15500406000010	Ecrou flare	1			
46	15500406000016	Ecrou flare	1			
53	17222000A07041	Carte display ens	1			
53.1	1PR031389	Carte display	1			
53.2	12122000A03192	Boitier display	1			