




AW-HFT018-N11 - 7SP023115

P os	Numéro de pièce	Dénomination	Quantité	Q u.	Stock Dispo	Prochaine arrivée	Stock dispo à terme	Remplacant 2	Matching 3
1	12122000A 22740	Panneau			0		0		
2	1PR120211	Filtre			0		0		
3	17222000A 07066	Carte display ens			0		0		
3.1	1PR031389	Carte display			0		0		
4	121220000 06733	Capot			0		0		
5	1PR191189	Panneau			0		0		
5.1	121220000 08242	Cache vis			0		0		
6	121220000 04608	Support			0		0		
8	1PR160899	Volet			0		0		
9	158220000 10100	Evaporateur			0		0		
10	121220000 05512	Capot			0		0		
11	1PR060098	Moteur ventilateur			0		0		
12	1PR160499	Support			0		0		
13	1PR160474	Roulement			0		0		
14	1PR110455	Turbine			0		0		
16	12122000A 03046	Chassis			0		0		
16 .1	1PR090036	Moteur volet			0		0		
16 .1	1PR060596	Moteur volet			0		0		
16 .3	1PR110480	Volet			0		0		
16 .4	121220000 04614	Capot			0		0		

AW-HFT018-N11 - 7SP023115

P os	Numéro de pièce	Dénomination	Quantité	Q u.	Stock Dispo	Prochaine arrivée	Stock dispo à terme	Remplacant 2	Matching 3
17	121220000 12942	Support			0		0		
18	1PR160005	Support mural			0		0		
19	172220000 27293	Carte electronique ens			0		0		
19 .4	1PR031401	Carte electronique			0		0		
19 .5	1PR070498	Sonde temperature			0		0		
19 .6	1PR070477	Sonde temperature			0		0		
19 .7	174004010 00285	Bornier electrique			0		0		
19 .8	1PR100193	Transformateur			0		0		
19 .9	121220000 20327	Boitier electrique			0		0		
19 .11	171220000 15780	Support			0		0		
20	121220000 05024	Capot			0		0		
21	7ACEL1740	Telecommande IR RC08C AW			0		0		
28	1PR160464	Raccord			0		0		
40	1PR120038	Filtre			0		0		
42	155002090 00001	Vanne detection fuite			0		0		
45	1PR160670	Support telecommande RC08			0		0		
46	155004060 00003	Ecrou flare			0		0		
46	155004060 00016	Ecrou flare			0		0		