




AWSI-HOD012S-N11

Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2
1	1PR190786	Panneau	1			
2	1PR031198	Carte display	1			
3	1PR120086	Filtre	2			
4	1PR190752	Panneau	1			
5	1PR160418	Guide volet	1			
6	1PR160417	Guide volet	1			
7	1PR160026	Axe	3			
8	1PR110354	Volet	1			
9	1PR110228	Helice	1			
10	1PR160201	Bague axe gauche	2			
11	1PR090059	Moteur volet	1			
12	1PR160338	Bague axe turbine	1			
13	1PR160245	Roulement	1			
15	G24212114	Support evapourateur	1			
17	1PR150410	Evaporateur	1			
18	1PR110277	Turbine	1			
19	1PR160257	Tube condensats	1			
20	1PR060151	Moteur ventilateur	1			
21	1PR160856	Support	1			
22	G26112209	Support moteur ventilateur	1			
23	1PR160832	Bouchon	1			
24	G2611216402	Support tubing	1			
25	1PR160329	Bac condensats	1			
26	1PR160244	Reducteur	2			

