




AWSI-HOD018-N11

Pos	Numéro de pièce	Dénomination	Quantité	Qu.	Info	remplacant 2	M a t c h i n g
1	1PR190234	(B-C) Panneau	1				
2	1PR031199	Carte display	1				
3	1PR120124	Filtre a air	2				
4	G24252016	(B-C) Cache vis	3				
5	1PR190742	Panneau	1				
6	1PR160419	Guide volet	1				
7	1PR110136	(B-C) Guide volet	1				
8	1PR110229	Helice	1				
9	1PR160182	(B-C)Left Axile bush	2				
10	1PR090049	(B-C)Moteur volet	1				
11	1PR160227	Palier	1				
12	1PR100420	Anneau de roulement	1				
13	1PR110281	Turbine	1				
14	G24212139	Support Evaporateur	1				
15	G0100238601	Evaporateur	1				
16	1PR160661	Support mural	1				
17	G26112330	moteur	1				
18	1PR060429	(B-C)Moteur ventilateur	1				
19	1PR160686	Tube condensats	1				
20	G26112188	(CNR)Support	1				
21	1PR190766	Panneau	1				
22	1PR090050	(B-C)Moteur volet	1				
23	1PR090034	Moteur volet	1				
24	1PR160026	Axe	2				

[illegible]