

This exploded view diagram illustrates the assembly of the RXM20YVMA washing machine. The components are organized into several main sections:

- Top Section:** Includes the main body (B1), top panel (F17), and various internal components like the motor (E16), pump (E13-1, E13-2, E13-3), and wiring (E27, E28, E22).
- Front Section:** Shows the front door (F4), door gasket (C4), and door handle (F9). The door is secured with screws (F15).
- Internal Components:** Includes the motor (E16), pump (E13-1, E13-2, E13-3), and various wiring (E27, E28, E22).
- Bottom Section:** Shows the base (A7), base panel (A8), and various internal components like the motor (E16), pump (E13-1, E13-2, E13-3), and wiring (E27, E28, E22).
- Accessories:** Includes the detergent drawer (F3), detergent drawer handle (F9), and various internal components like the motor (E16), pump (E13-1, E13-2, E13-3), and wiring (E27, E28, E22).

The diagram uses alphanumeric labels (A1 through F26) to identify each part, and dashed lines indicate the assembly path and relative positions of the components.