



FOR SELECTION OF THE THERMISTORS AND WIRE HARNESSES  
REFER TO THE SPARE PARTS LIST-SEE WIRING SYMBOL.



