

This exploded view diagram illustrates the assembly of the A85CVMA unit. The components are organized into several main sections, each identified by a letter and a number:

- Top Section (F1, F25, F18, F17):** Includes the main top cover (F1) and associated mounting hardware (F25, F18, F17).
- Front Panel (F16, F6, F4, F26):** Shows the front bezel (F16) and its mounting brackets (F6, F4, F26).
- Internal Components (C1, C1-1, C1-2, C1-3, C1-4, C1-9, C1-10, C1-11, C1-12, C1-13, C1-14, C1-15, C1-16, C1-17, C1-18, C1-19):** Details the internal mechanical and electrical components, including the main assembly (C1) and various sub-components (C1-1 through C1-19).
- Bottom Section (B1, B1-1, B1-2, B1-3, B1-4, B1-5, B1-6, B1-7, B1-8, B1-9, B1-10, B1-11, B1-12):** Shows the bottom housing (B1) and its internal components (B1-1 through B1-12).
- Electrical Components (E1, E2, E3, E4, E5, E6, E7, E8, E9, E10, E11, E12, E13, E14, E15, E16, E17, E18-1, E18-2):** Details the electrical control components, including the main assembly (E1) and various sub-components (E2 through E18-2).
- Accessories (K1, K2, K3, K4, K5, K6, K7, K8, K9, K10, K11, K12, K13):** Shows various accessories and mounting hardware (K1 through K13).

The diagram uses alphanumeric labels to identify each part, and arrows indicate the assembly sequence and orientation. A note "A View" is present near the bottom right section.

A View