


<141573-01> <141574-01> <141577-01> <141578-01> <141581-01> <141582-01> <141585-01> <141586-01>
<EHS04P30BB> <EHSB04P30BB> <EHSX04P30BB> <EHSXB04P30BB> <EHS08P30BB>
<EHSB08P30BB> <EHSX08P30BB> <EHSXB08P30BB>

EHSxxxP30BB / 1415xx

- A
- B
- C



HPSU compact

The diagram is an exploded view of a water heater assembly. It shows the main tank (B13) at the top right, the control panel (B2) at the bottom center, and various internal and external components. The components are labeled with codes and positions:

- Top Section:** B14 (top tank), B15 (cap), B30 (flange), B33 (seal), B33 (seal), B13 (main tank), B12 (valve), B26 (seal), B8 (seal), B29 (elbow), B11 (cap), B3 (valve), B10 (seal), B12 (valve), B16 (seal), B24 (cap), B20 (seal), B28 (seal), B9 (seal), B11 (cap), B8 (seal), B16 (seal), B23 (cap), B20 (seal), B28 (seal), B9 (seal).
- Middle Section:** B24 (cap), B12 (valve), B8 (seal), B9 (seal), B17 (valve), B17 (valve), B6 (cap), B5 (cap), B8 (seal), B9 (seal), B17 (valve), B7 (cap), B19 (cap), B25 (cap), B18 (cap), B20 (seal), B21 (cap), B28 (cap), B22 (cap), B4 (cap), B35 (cap), B31 (cap), B32 (cap), B2 (control panel), B20 (seal), B28 (seal), B9 (seal), B16 (seal), B23 (cap), B20 (seal), B28 (seal), B9 (seal).
- Bottom Section:** J12 (Pos A9), J12 (Pos A10), J9 (Pos A12), J5 (Pos A18), J1 (Pos A11), J7 (Pos A13), X6A (Pos A21), X5A (Pos A20), X8A (Pos A22).

A legend on the left indicates three levels: A (top), B (middle), and C (bottom).

HPSU compact

EHSxxxP30BA / 1415xx

