


<141573-01> <141574-01> <141577-01> <141578-01> <141581-01> <141582-01> <141585-01> <141586-01>
<EHS04P30BB> <EHSB04P30BB> <EHSX04P30BB> <EHSXB04P30BB> <EHS08P30BB>
<EHSB08P30BB> <EHSX08P30BB> <EHSXB08P30BB>

EHSxxxP30BB / 1415xx

- A
- B
- C



HPSU compact

The diagram is an exploded view of a water heater assembly. It shows the main tank (B13) at the top right, the control panel (B2) at the bottom center, and various internal and external components. The components are labeled with codes and positions:

- Top Section:** B14 (top tank), B15 (flange), B30 (valve), B33 (seal), B33 (seal).
- Control Panel Area:** B12 (valve), B8 (flange), B9 (seal), B17 (valve), B6 (valve), B5 (valve), B8 (flange), B9 (seal), B17 (valve), B35 (valve), B31 (valve), B32 (valve), B2 (control panel), B21 (valve), B28 (valve), B22 (valve), B20 (valve), B28 (valve), B9 (seal), B16 (valve), B8 (flange), B11 (valve), B9 (seal), B23 (valve), B8 (flange), B11 (valve), B9 (seal).
- Internal Components:** B24 (valve), B12 (valve), B8 (flange), B9 (seal), B17 (valve), B6 (valve), B5 (valve), B8 (flange), B9 (seal), B17 (valve), B35 (valve), B31 (valve), B32 (valve), B2 (control panel), B21 (valve), B28 (valve), B22 (valve), B20 (valve), B28 (valve), B9 (seal), B16 (valve), B8 (flange), B11 (valve), B9 (seal), B23 (valve), B8 (flange), B11 (valve), B9 (seal).
- Electrical Components:** J12 (Pos A9), J12 (Pos A10), J9 (Pos A12), J5 (Pos A18), J1 (Pos A11), J7 (Pos A13), X6A (Pos A21), X5A (Pos A20), X8A (Pos A22).

A legend on the left indicates three levels: A (top), B (middle), and C (bottom).

<141577-01> <141578-01> <141585-01> <141586-01>
 <EHSB04P30BB> <EHSXB04P30BB> <EHSB08P30BB> <EHSXB08P30BB>

HPSU compact

EHSxBxxP30BB / 1415xx

