




| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-3.0RW1E-220S-K

|      |        |                      |    |                                                                                       |
|------|--------|----------------------|----|---------------------------------------------------------------------------------------|
| 1    | E04869 | FOOT                 | 4  |                                                                                       |
| 2    | E04088 | TANK HEATER          | 1  | Tank Heater + Thermostat + O-Ring.                                                    |
| 2-2  | E06116 | O-Ring               | 1  | Only O-Ring for Tank Heater sealing.                                                  |
| 4    | E07087 | TH INSULATION        | 2  | Cover for tank surface thermistors.                                                   |
| 5    | E07088 | SIDE COVER L         | 1  |                                                                                       |
| 6    | E07089 | SIDE COVER R         | 1  |                                                                                       |
| 7    | E07090 | EXPANSION VESSEL 6L  | 1  |                                                                                       |
| 8    | E07091 | FLEXIBLE PIPE        | 1  | For Expansion Vessel.                                                                 |
| 9    | E07092 | FLEXIBLE PIPE        | 2  | For tank coil connections.                                                            |
| 10   | E07095 | PHEx UNIT            | 1  | Assembly.                                                                             |
| 10-1 | E04896 | PLATE HEX            | 1  |                                                                                       |
| 10-2 | E07099 | EXP. VALVE ASSY      | 1  | Exp.Valve + Pipes + Strainers + Silencer.                                             |
| 10-3 | E03077 | EXPANSION VALVE      | 1  |                                                                                       |
| 10-4 | E06198 | Seal Nut             | 1  |                                                                                       |
| 11   | E02488 | UNION                | 1  | Gas connection.                                                                       |
| 12   | R4227  | Flare Nut            | 1  | Gas connection.                                                                       |
| 13   | E02487 | UNION                | 1  | Liquid connection.                                                                    |
| 14   | R4225  | Flare Nut            | 1  | Liquid connection.                                                                    |
| 15   | E07102 | WATER PUMP           | 1  |                                                                                       |
| 16   | E07104 | ELECTRIC HEATER      | 1  |                                                                                       |
| 17   | E03832 | Gasket               | 6  | For Pump and Shutdown Valves connections.                                             |
| 18   | E07106 | FILTER BALL          | 1  |                                                                                       |
| 18-1 | E04841 | FILTER               | 1  |                                                                                       |
| 18-2 | E04842 | SEEGER               | 1  |                                                                                       |
| 19   | E07107 | ORING                | 13 | For Quick Connections sealing.                                                        |
| 20   | E07108 | CLAMP                | 10 |                                                                                       |
| 21   | E07109 | CLAMP                | 3  |                                                                                       |
| 23   | E07111 | CLAMP                | 1  | For Pressure Sensor connection.                                                       |
| 24   | E07112 | 3 WAY VALVE          | 1  |                                                                                       |
| 25   | E07113 | SECURITY VALVE       | 1  |                                                                                       |
| 26   | E02507 | UNION                | 1  |                                                                                       |
| 27   | E07114 | AIR PURGE            | 1  |                                                                                       |
| 28   | E06307 | Air Purge            | 1  |  |
| 29   | E07225 | GEN 2.5 WRC ASM ASSY | 1  |                                                                                       |
| 30   | E07116 | MANOMETER            | 1  |                                                                                       |
| 31   | E07117 | E-BOX COVER ASSY     | 1  | Plate + Labels.                                                                       |
| 32   | E02549 | P-SPRING             | 1  |                                                                                       |
| 33   | E02550 | P-SPRING             | 1  |                                                                                       |
| 34   | E01897 | HANDLE               | 4  |                                                                                       |
| 35   | E02497 | GASKET               | 2  | For Vessel and Seal Nut connections.                                                  |
| 36   | E02501 | Screw                | 2  |                                                                                       |
| 37   | E02548 | WASHER               | 2  |                                                                                       |
| 38   | E02547 | NYLON WASHER         | 2  |                                                                                       |
| 39   | E04954 | GASKET               | 2  | For DHWT In/Out connections.                                                          |
| 40   | E05019 | SHUTDOWN VALVE       | 2  |                                                                                       |
| 41   | E07118 | THERMISTOR ASSY      | 1  | Water In THM.                                                                         |
| 42   | E07119 | THERMISTOR ASSY      | 1  | Water Out THM.                                                                        |
| 43   | E07120 | THERMISTOR ASSY      | 1  | Water Out PHEx THM.                                                                   |
| 44   | E07121 | THERMISTOR ASSY      | 1  | Liquid THM.                                                                           |

# MODULE HYDRAULIQUE

## RWD-3.0RW1E-220S-K

|      |        |                         |   |                                   |
|------|--------|-------------------------|---|-----------------------------------|
| 45   | E04982 | THERMISTOR ASSY 2       | 1 | Gas THM.                          |
| 46   | E04965 | EXP. VALVE COIL         | 1 |                                   |
| 47   | E07122 | THERMISTOR ASSY         | 1 | Tank surface.                     |
| 48   | E07123 | THERMISTOR ASSY         | 1 | Tank surface.                     |
| 49   | E07124 | SCREW ( THERMOPLASTIC ) | 6 | For water thermistors.            |
| 50   | E07125 | COMPOSITE 1             | 1 |                                   |
| 51   | E07126 | COMPOSITE 2             | 1 |                                   |
| 52   | E07127 | COMPOSITE 3             | 1 |                                   |
| 53   | E07128 | PLUG                    | 2 |                                   |
| 54   | E07129 | DRAIN PAN               | 1 |                                   |
| 55   | E02012 | CLAMP                   | 2 |                                   |
| 56   | E07227 | PRESSURE SENSOR         | 1 |                                   |
| 57   | E07131 | SERVICE COVER ASSY      | 1 | Service Cover + LCD Frame + Label |
| 57-1 | E07132 | LCD FRAME               | 1 |                                   |
| 57-2 | E07226 | HITACHI LABEL           | 1 |                                   |
| 58   | E01999 | RUBBER BUSHING          | 2 |                                   |

# MODULE HYDRAULIQUE


## RWD-3.0RW1E-220S-K

Pièces détachées

Main view

LOCATION OF SERVICE PARTS IN THE UNIT  
<Electrical Box>

MODEL:  
RWD-(2.0-3.0)RW1E-220S(-K)  
RWD-(4.0-6.0)RW1E-220S(-K)



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-3.0RW1E-220S-K

|    |        |                           |    |                                  |
|----|--------|---------------------------|----|----------------------------------|
| 1  | E07070 | INSTRUCTION ASSY PCB      | 1  |                                  |
| 2  | E01789 | SPACER                    | 12 |                                  |
| 3  | E02519 | TERMINAL BOARD            | 1  |                                  |
| 4  | E04778 | TERMINAL BOARD            | 1  |                                  |
| 5  | E04779 | RELAY                     | 3  |                                  |
| 6  | E04780 | FUSE                      | 3  | 6,3A                             |
| 7  | E04782 | FUSE                      | 1  | 20A                              |
| 8  | E02516 | FUSE HOLDER               | 4  |                                  |
| 9  | E04785 | THERMOSTAT                | 1  |                                  |
| 10 | E07134 | ROCKER SWITCH             | 1  |                                  |
| 11 | E02060 | RUBBER BUSH               | 2  |                                  |
| 12 | E07135 | ELECTRICAL WIRING DIAGRAM | 1  | Assembly (Components + Harness). |
| 13 | E07137 | E-BOX SUB ASSY            | 1  | Only plate (without components). |