


# MODULE HYDRAULIQUE

## RWD-5.0HFSNWE-200S

Pièces détachées

Main view



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-5.0HFSNWE-200S

|      |        |                      |   |                                                                  |
|------|--------|----------------------|---|------------------------------------------------------------------|
| 1    | E04039 | ELECTRIC HEATER UNIT | 1 | Gaskets not included                                             |
| 2    | E04040 | AIR PURGE            | 1 |                                                                  |
| 3    | E02475 | SECURITY VALVE       | 1 |                                                                  |
| 4    | E02476 | EXPANSION VESSEL 6L  | 1 |                                                                  |
| 5    | E04042 | PUMP                 | 1 | Gaskets and Pump Insulation 30 not included                      |
| 6    | E04043 | FLOW METER ASSY      | 1 | Gaskets not included                                             |
| 7    | E04047 | PHEX UNIT            | 1 | Assembly ( 7- 1 to 7- 3 included)                                |
| 7-1  | E02485 | PLATE HEX            | 1 |                                                                  |
| 7-2  | E01716 | EXP. VALVE           | 1 |                                                                  |
| 7-3  | E01206 | STRAINER             | 2 |                                                                  |
| 8    | E03749 | Water Strainer       | 1 | Body + Mesh + Gasket                                             |
| 8-1  | E03750 | Mesh                 | 1 | Ã36 x L43                                                        |
| 8-2  | E03751 | Gasket               | 1 | Ã41, 4 x Ã36, 2 x Ã2, 6                                          |
| 9    | E02487 | UNION                | 1 | Liquid Connection                                                |
| 10   | E02488 | UNION                | 1 | Gas Connection                                                   |
| 11   | E02489 | FLARE NUT            | 1 | Liquid Connection                                                |
| 12   | E02490 | FLARE NUT            | 1 | Gas Connection                                                   |
| 13   | E04048 | FLEXIBLE PIPE        | 1 | Vessel Connection                                                |
| 14   | E03800 | MANOMETER            | 1 |                                                                  |
| 15   | E02494 | PRESSURE SW          | 1 |                                                                  |
| 16   | E04049 | LCD CONTROL          | 1 |                                                                  |
| 17   | E02496 | GASKET               | 4 | for Electric Heater and Pump connections                         |
| 18   | E02497 | GASKET               | 2 | for Mini Valves connection                                       |
| 19   | E04050 | GASKET               | 2 | for Flow Meter connections                                       |
| 20   | E02528 | GASKET               | 5 | for 3 Way Valve and Tank Coil connections ( 1" )                 |
| 21   | E04051 | GASKET               | 2 | for Water IN/OUT ( 1- 1/4" )                                     |
| 22   | E04052 | GASKET               | 4 | for Tank Water IN/OUT and DHWT IN/OUT ( 3/4" )                   |
| 23   | E04053 | UPPER COVER          | 1 |                                                                  |
| 24   | E04054 | SERVICE COVER ASSY   | 1 | Assembly ( Screws and Washers not included)                      |
| 24-1 | E02499 | LCD COVER            | 1 | Assembly ( LCD Cover + Shaft + Washers)                          |
| 24-2 | E02500 | MAGNET               | 2 |                                                                  |
| 25   | E02501 | Screw                | 4 | for Service Cover Assy and Upper Cover fixing                    |
| 26   | E02547 | NYLON WASHER         | 4 | for Service Cover Assy and Upper Cover fixing ( material: nylon) |
| 27   | E02548 | WASHER               | 4 | for Service Cover Assy and Upper Cover fixing ( material: steel) |
| 28   | E04055 | SHUTDOWN VALVE       | 2 |                                                                  |
| 29   | E02060 | RUBBER BUSH          | 3 |                                                                  |
| 30   | E04056 | PUMP INSULATION      | 1 | only insulation around the Pump                                  |
| 31   | E02507 | UNION                | 1 | for Security Valve drain connection                              |
| 32   | E04057 | THERMISTOR ASSY 1    | 1 | THM DHWT ( Tank surface)                                         |
| 33   | E04058 | THERMISTOR ASSY 1    | 1 | THM WI ( Water In)                                               |
| 34   | E04059 | THERMISTOR ASSY 1    | 1 | THM WO ( Water Out)                                              |
| 35   | E04060 | THERMISTOR ASSY 2    | 1 | THM G ( Gas)                                                     |
| 36   | E04061 | THERMISTOR ASSY 2    | 1 | THM L ( Liquid)                                                  |
| 37   | E04062 | THERMISTOR ASSY 2    | 1 | THM WOHP ( Water Out PHEX)                                       |
| 38   | E02546 | DRAIN PIPE           | 1 | Vinyl Tube ( diameter 16mm - 1 meter length)                     |
| 39   | E02549 | P-SPRING             | 1 | for liquid THM fixing                                            |
| 40   | E02550 | P-SPRING             | 1 | for gas THM fixing                                               |

## MODULE HYDRAULIQUE

### RWD-5.0HFSNWE-200S

|      |        |                  |   |                                                     |
|------|--------|------------------|---|-----------------------------------------------------|
| 41   | E02551 | P-SPRING         | 6 | for water THM fixing                                |
| 42   | E04063 | CONTROL SUPPORT  | 1 |                                                     |
| 43   | E04064 | 3 WAY VALVE ASSY | 1 | Gaskets not included                                |
| 44   | E03247 | FOOT             | 4 |                                                     |
| 45   | E04083 | WATER TANK 200L  | 1 | Gaskets not included                                |
| 45-1 | E04088 | TANK HEATER      | 1 | 2, 75 kw ( Thermostat and gasket D57x3, 5 included) |
| 46   | E04084 | FRONT INSULATION | 1 | for Water Tank Insulation                           |
| 47   | E04085 | BACK INSULATION  | 1 | for Water Tank Insulation                           |
| 48   | E04068 | TH INSULATION    | 1 | for Water Tank Insulation                           |
| 49   | E04069 | MINI VALVE       | 2 | Gaskets not included                                |
| 50   | E01897 | HANDLE           | 2 |                                                     |
| 52   | E02531 | Union            | 5 | Water Connections 1"                                |
| 53   | E04071 | UNION            | 2 | Water Connections 1- 1/4"                           |
| 54   | E04072 | UNION            | 3 | Water Connections 3/4"                              |
| 55   | E04073 | UNION            | 1 | Water Connections 3/4" ( with bending)              |
| 56   | E04074 | UNION            | 2 | Flow Meter Connections                              |
| 57   | E04075 | NUT              | 2 | Flow Meter Connections                              |

# MODULE HYDRAULIQUE


## RWD-5.0HFSNWE-200S

Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT  
ELECTRICAL EQUIPMENT

RWD-2.0(H)FSNWE-200S  
RWD-3.0(H)FSNWE-200S  
RWD-4.0(H)FSNWE-200S  
RWD-5.0(H)FSNWE-200S  
RWD-6.0(H)FSNWE-200S  
RWD-2.0(H)FSNWE-200S  
RWD-3.0(H)FSNWE-200S  
RWD-4.0(H)FSNWE-200S  
RWD-5.0(H)FSNWE-200S  
RWD-6.0(H)FSNWE-200S



HITACHI

10110

EPN-201400A-30

| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-5.0HFSNWE-200S

|    |         |                    |    |                                     |
|----|---------|--------------------|----|-------------------------------------|
| 1  | E03829  | PCB1               | 1  |                                     |
| 2  | E03774  | PCB                | 1  |                                     |
| 3  | E04076  | TRANSFORMER 1      | 1  |                                     |
| 4  | E04077  | TRANSFORMER 2      | 1  |                                     |
| 5  | E02198  | RELAY              | 1  | 15 A                                |
| 6  | E00003  | FUSE               | 1  | 3, 15 A                             |
| 7  | EC00071 | FUSE               | 3  | 12 A                                |
| 8  | EC00454 | FUSE               | 1  | 16 A                                |
| 9  | E02516  | FUSE HOLDER        | 1  |                                     |
| 10 | E01015  | FUSE HOLDER        | 4  |                                     |
| 11 | E02517  | MAGNETIC CONTACTOR | 2  | 12 A                                |
| 12 | E02792  | TERMINAL BOARD     | 1  |                                     |
| 13 | E02519  | TERMINAL BOARD     | 1  |                                     |
| 14 | P19112  | SPACER             | 10 |                                     |
| 15 | P14366  | SURGE ABSORBER     | 7  |                                     |
| 16 | E02012  | CLAMP              | 1  |                                     |
| 17 | E02060  | RUBBER BUSH        | 9  |                                     |
| 18 | E04079  | ELECTRICAL BOX     | 1  | Assembly ( Components +<br>Harness) |
| 19 | E04080  | E-BOX COVER ASSY   | 1  | ( Plate + Labels)                   |
| 20 | E04081  | E-BOX SUB ASSY     | 1  | Only plate ( without<br>components) |
| 21 | E03828  | Rocker Swith       | 1  |                                     |
| 22 | E04082  | THERMOSTAT         | 1  |                                     |