


CONSOLE

RPF-1.5FSNE

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CONSOLE

RPF-1.5FSNE

U00	E00750	TERMINAL BOARD	1	
U02	E00972	PC-ART	1	PC- P1HE (Optional)
U13	E00679	EXP. VALVE CORD	1	
U14	E01005	CAPACITOR	1	2μ F
U15A	E00876	THERMISTOR	1	Inlet
U15B	E00939	THERMISTOR	1	Gas
U15C	E00935	THERMISTOR	1	Liquid
U15D	E00877	THERMISTOR	1	Outlet
U21	E00580	EXPANSION VALVE	1	
U31	E00583	AIR FILTER	1	
U34A	E00848	D GRILLE	7	Air Outlet
U34C	E00870	INLET G WORK	3	Air Inlet
U36	P16834	RUNNER	2	
U37	P17290	FAN CASING	2	
U41	E00587	HEAT EXCHANGER	1	Assembly
U65A	P19112	SPACER	4	For fixing PCB
U65B	E00738	PUSH SPACER	2	For fixing PCB
U65C	E00868	GRILLE KNOB	6	
U71	E00859	FAN MOTOR	1	
U82	E00744	TRANSFORMER	1	
U85	E00930	PCB	1	
U98A	E00592	BACK COVER ASSY	1	Assembly
U98B	E00866	FRONT COVER ASSY	1	Assembly
U98C	E00871	SIDE COVER ASSY	2	Assembly
U98D	E00996	U-COVER ASSY	1	