


MONOSPLIT

RASM-4VR1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-4VR1E


2	XEK13501A	COMPRESSOR	1	
3	E06435	TERMINAL COVER - 4CY00988	1	
4	E06436	GASKET - 4CYC01047	1	
5	E06437	NUT - 3CY00004	1	
6	E06438	RUBBER WASHER - 4CYC00174	1	
7	E06439	SLEEVE - 4CYC01042	1	
8	E06877	THERMAL CUT-OUT	1	
9	E06433	RUBBER GROMMET	3	
10	P21245	SPECIAL NUT	2	
11	E06434	TERMINAL COVER - 4CY00997	3	
12	1000011421	CONDENSER ASSY	1	Assembly
12-1	E06367	HEADER G ASSY	1	Assembly
12-2	1000011453	Header L Assy	1	Assembly
40940	1000011454	EVO Assy	1	Assembly
12-2-1-2	P25037	STRAINER	2	
12-3	E02107	END PLATE ASSY	1	
13	E02105	ATTACHING PLATE	1	
14	E06845	ACCUMULATOR	1	
15	1000011472	Pipe S Assy	1	Assembly
15-1	P24399	STRAINER	1	
15-2	E06312	P-SENSOR (S)	1	(S)
16	1000011432	4-Way Valve Assy	1	Assembly
17	1000011464	Economizer Unit	1	Assembly
18	1000011459	Partition Assy	1	
19	E03363	V-Stay	1	
20	XEK52845A	VALVE STAY	1	
21	E06334	CLAMP L ASSY	1	Assembly
22	E06110	Fan Motor	2	
23	E06482	PROPELLER FAN	2	
24	E06379	SHROUD S ASSY	1	Assembly
24-1	E06317	SHROUD S	1	
24-2	E02876	AIR GRILLE	2	Air Outlet
24-3	E01897	HANDLE	1	
25	E05855	SIDE COVER LB	1	
26	E05954	EXPV COIL	1	Coil for Expansion Valve
30	E06311	C-HEATER	1	
33	E06600	Thermistor Assy	1	Te
35	E06598	Thermistor Assy	1	Ta
36	E01901	TH PLATE	1	
37	XEK26452R	THERMISTOR ASSY	1	Ts
63	1000011467	Rear Cover L Assy	1	Assembly
63-1	P23833	H COVER	1	
63-2	E01897	HANDLE	1	
64	E02148	U-COVER ASSY	1	Assembly
65	1000011466	S Cover B Assy	1	
66	1000011437	Service Cover L Assy	1	Assembly
67	E01897	HANDLE	1	
68	E04824	GASKET	4	
69	XEK26629B	Acoustical Cover	1	
70	E06370	ACOUSTICAL COVER 2 (UP)	1	

MONOSPLIT

RASM-4VR1E

Pièces détachées

Main view



MONOSPLIT

RASM-4VR1E


16-1	E05578	Reversing Valve	1	RVR
16-2	1000011458	D Pipe Assy	1	Assembly
42401	P28629	Silencer	1	
42402	P29897	Check Valve	1	
42403	E04508	P-Sensor	1	PSC (Control)
42404	E03359	PRESSURE SW	1	PSH (High)
16-3	1000011473	SVA Assy	1	Assembly
42430	E06838	CAPILLARY	1	
42431	P25246	SOLENOID VALVE	1	SVA
16-4	1000011474	SVA Assy	1	Assembly
42461	17H07462C	Capillary	1	
42462	P25246	SOLENOID VALVE	1	SVC
16-5	E01160	CHECK JOINT	1	
16-6	E01512	Stop Valve	1	5/8
17-1	XEK27444A	ECONOMIZER	1	
17-2	P25246	SOLENOID VALVE	1	
17-3	P25036	FILTRE DETENDEUR	1	
17-5	E03077	EXPANSION VALVE	1	
17-6	E06485	Stop Valve	1	3/8
27	1000011716	Coil Harness	1	RVR
28	1000011717	Coil Harness	1	SVA
29	1000011468	Coil Harness	1	SVC
31	E06597	Thermistor Assy	1	Td
32	17G27651A	P-Spring	1	
33	E06600	Thermistor Assy	1	Te
34	E05646	TH-PLATE	1	
35	E06598	Thermistor Assy	1	Ta
36	E01901	TH PLATE	1	
37	XEK26452R	THERMISTOR ASSY	1	Ts
38	E02444	P-SPRING	1	
39	XEK26452Q	THERMISTOR ASSY	1	Teco
40	17G27651D	P-Spring	1	
41	E03180	EXPANSION VALVE COIL	1	Coil for Expansion Valve
42	E03291	EXPV COIL	1	Coil for Expansion Valve
43	1000011469	COIL HARNESS	1	SVE

MONOSPLIT

RASM-4VR1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-4VR1E


44	1000011460	PHEX Unit	1	Assembly
44-1	E06535	PLATE HEX	1	
44-2	XEK53017A	WH HEATER	1	
45	E04893	EXPANSION VESSEL (6L)	1	
46	E02497	GASKET	1	
47	E07103	WATER PUMP	1	
48	E03832	Gasket	2	
49	E04840	FILTER BALL	1	
49-1	E04841	FILTER	1	
49-2	E04842	SEEGER	1	
50	E02528	GASKET	2	
51	E04040	AIR PURGE	1	
52	E02475	SECURITY VALVE	1	
53	E04873	GASKET	1	
54	E02507	UNION	1	
55	E02546	DRAIN PIPE	1	
56	E07143	THERMISTOR ASSY 1	1	Water In Thermistor
57	E04929	THERMISTOR ASSY 1	1	Water Out Thermistor
58	E02551	P-SPRING	2	
59	E04991	THERMISTOR ASSY 2	1	Gas Thermistor
60	E02550	P-SPRING	1	
61	E04931	THERMISTOR ASSY 2	1	Liquid Thermistor
62	E02549	P-SPRING	1	

MONOSPLIT

RASM-4VR1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-4VR1E


1	1000011423	Electrical Box	1	Assembly
2-1	E06676	E-BOX PCB SUB ASSY	1	Assembly
2-2	E01818	TERMINAL BOARD	1	
2-3	E06310	DSW PCB	1	
2-4	E04603	SPACER	13	
2-5	E06329	FAN PCB ASSY	1	
2-6	E06457	Reactor	1	
3	1000011434	E-Box INV Unit	1	Assembly
3-1	1000010704	PCB	1	
3-2	E06448	Spacer	4	
3-3	E06449	Plastic Nut	4	
3-4	E06407	PLATE INV ASSY	1	
4	E06406	E-BOX UPPER SUPPORT	1	
5	XEK52965A	Support Ebox	1	

MONOSPLIT

RASM-4VR1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-4VR1E

1	1000011427	Electrical Box	1	Assembly
2	EC7C42	E-BOX	1	
3	1000011412	PCB	1	
4	E01789	SPACER	12	
5	EC4778	TERMINAL BOARD	1	
6	EC4779	RELAY	1	
7	EC4782	FUSE	1	20A
8	EC2516	FUSE HOLDER	1	
9	E07134	ROCKER SWITCH	1	
10	EC4783	HARNESS LIFTER	3	
11	EC4784	ENDLING SADDLE	2	