


CASSETTE

RCI-1.0FSN2E


Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT FOR MODELS:
RCI-1.0FSN2E, RCI-1.5FSN2E, RCI-2.0FSN2E, RCI-2.5FSN2E, RCI-3.0FSN2E,
RCI-4.0FSN2E, RCI-5.0FSN2E, RCI-6.0FSN2E



LOCATION OF ELECTRICAL EQUIPMENT IN THE ELECTRICAL CONTROL BOX



HITACHI

PAGE 4/4
EPN-200802F-1B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CASSETTE

RCI-1.0FSN2E

U00A	E01088	TERMINAL BOARD	1	
U00B	E01089	TERMINAL BOARD	1	
U00C	E02444	P-SPRING	1	FOR GAS PIPE. Only for Thermistor E02443 (17B41046 E)
U00C	E01194	S-SPRING	1	FOR GAS PIPE. Only for Thermistor E01184 (17B24543 E)
U02	E01693	PC-ART	1	PC- ART (OPTIONAL)
U13	E01724	ELECTRICAL BOX	1	Assembly (Components + Harness)
U14	E01091	CAPACITOR ASSY	1	
U15A	E01203	THERMISTOR	1	AIR INLET
U15B	E02875	THERMISTOR	1	AIR OUTLET
U15C	E02443	THERMISTOR	1	GAS PIPE
U15D	E01198	THERMISTOR	1	LIQUID PIPE
U21	P22422	EXPANSION VALVE	1	
U36	E03982	Turbo Fan Assy	1	 TURBO FAN KIT (Turbo Fan + Rubbers + Instruction)
U41	E01097	HEAT EXCHANGER	1	ASSEMBLY
U65A	E02931	SPACER	14	
U71A	E01100	FAN MOTOR	1	
U71B	E01101	DRAIN PUMP	1	DISCHARGE MECHANISM
U82	E01294	TRANSFORMER	1	
U85A	E01688	PCB	1	PI064 (Main PCB)
U85B	E01105	PI012 ASSY	1	PI012 Assy (For Power Supply)
U85C	E01106	PI979 Assy	1	PI979 Assy (For Noise Protection)
U87	E01107	FLOAT SW	1	
U97	E01720	DRAIN PAN	1	ASSEMBLY
U98	E03756	MB ASSY	1	(Drain Pan + Bellmouth + Insulations)