

MURAL


RPK-0.8FSN3M

Pièces détachées

Main view

LOCATION OF SERVICE PARTS IN THE UNIT

MODEL: RPK-0.8FSN3M
RPK-0.8FSN3M
RPK-1.0FSN3M



A	Texas Head Tapping Screw		F	Blind Bolt	
B	Round Head Screw		G	Nut	
C	Hex Head Screw		H	Washer	
D	Flat Head Tapping Screw		J	Spring Lock Washer	
E	Hexagon Head Bolt		K	Toothed Lock Washer	

NOTE:
The recommended coating is applied to iron and steel material for the unspecified materials of the bolt and nut.

NOTE:
The parts without order number are the custom-ordered, and these are not mentioned in the price list.
When ordering them, the part name and the drawing number are required.
Contact your HWH distributor for the delivery date and price about them.

Rep. Référence

Description

Qté

Remarques

MURAL

RPK-0.8FSN3M

1	P29606	Heat Exchanger	1	
2	P27062	Drain Cap	1	
3	P28701	EXPANSION VALVE	1	Fujikoki Corporation, PAM-B40YGHS- 1
4	P29630	Motor for ExPV	1	Fujikoki Corporation, PAM-MD12HS- 11
5	P24016	THERMISTOR	1	THM1 for Air Inlet
6	P29626	Thermistor Air Outlet	1	THM2 for Air Outlet
7	P29628	Thermistor Freeze Protection	1	THM3 for Freeze Protection
8	P29627	Thermistor THM5 for Gas Line	1	THM5 for Gas Line
9	P29608	Fan Motor	1	DC, 38W
10	P29609	Motor Clamp	1	
11	P29610	Fan	1	
12	P26601	BEARING	1	
13	P29612	Bottom Base	1	
14	P29614	Corner Cover	1	
15	P29615	Drain Hose	1	
16	P29616	Pipe Cover	1	
17	P29636	Cabinet Panel Assy	1	Including part N° 31 Flat Panel
18	P29619	Filter	2	
19	P29621	Drain Pan Assy	1	
20	P29623	Plate	1	
21	P29624	As Motor	1	for Auto Swing Louver
22	P29518	PCB	1	PI- 121- S for Control
23	P29519	PCB-S	1	for Switch
24	P29625	PCB-S	1	for Receiver with Indicator
25	P26616	TERMINAL BLOCK	1	for Power Source Circuit
26	P26618	TERMINAL BLOCK	1	for Control Circuit
27	P27957	FUSE	2	Fuse on PI- 121- S, 5A
28	R4226	Flare Nut	1	Å12. 7
29	P29629	Screw Cap	2	
30	P29709	SWITCH COVER	1	
31	P29698	FLAT PANEL	1	Included in part N° 17 Cabinet Panel Assy