


# CENTRIFUGAL RASC-10HRNM1E

Pièces détachées

Main view



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                                               |   |                                                                                     |
|------|--------|-----------------------------------------------|---|-------------------------------------------------------------------------------------|
| 1    | E00705 | TERMINAL BOARD                                | 1 |                                                                                     |
| 2    | E02682 | CORD PS                                       | 1 | PSH ( Pressure Switch High)                                                         |
| 3    | E02683 | HARNESS PC                                    | 1 | PSC ( Pressure Switch Control)                                                      |
| 4    | P24776 | Fuse                                          | 2 | 40A                                                                                 |
| 5    | E03634 | Electrical Box                                | 1 | Assembly ( Components+ Harness+ Steel Plates+ Insulations)                          |
| 6    | P28496 | CAPACITOR                                     | 2 | 4700μ F                                                                             |
| 7    | E02684 | THERMISTOR                                    | 1 | For discharge gas temperature                                                       |
| 8    | E02685 | THERMISTOR                                    | 1 | For outdoor ambient temperature                                                     |
| 9    | E02686 | THERMISTOR                                    | 1 | For evaporating temperature                                                         |
| 10   | E03635 | Acoustial Cover                               | 1 |                                                                                     |
| 11   | P26740 | NOISE FILTER                                  | 1 |  |
| 12   | P27215 | TRANSISTOR M                                  | 1 | For Inverter                                                                        |
| 13   | P27214 | DIODE MODULE                                  | 1 | For Inverter                                                                        |
| 14   | E02024 | EXP. VALVE UNIT                               | 1 |                                                                                     |
| 14-1 | P26009 | COIL FOR EXP. VALVE                           | 1 |                                                                                     |
| 14-2 | P26008 | EXP. VALVE                                    | 1 |                                                                                     |
| 14-3 | P26471 | STRAINER                                      | 2 |                                                                                     |
| 14-4 | E02079 | EXP. VALVE CORD                               | 1 |                                                                                     |
| 15   | P26002 | STOP VALVE (référence du joint seul : P26149) | 1 | Gas Line                                                                            |
| 16   | E01511 | STOP VALVE                                    | 1 | Liquid Line                                                                         |
| 17   | E01160 | CHECK JOINT                                   | 1 | Check joint                                                                         |
| 18   | P21169 | DIST. STRAINER                                | 1 |                                                                                     |
| 19   | P24399 | STRAINER                                      | 1 |                                                                                     |
| 20   | P25036 | FILTRE DETENDEUR                              | 1 |                                                                                     |
| 21   | P13109 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 2                                                            |
| 22   | P17308 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 1                                                            |
| 23   | E03724 | Inlet Protector Net                           | 1 | Inlet                                                                               |
| 24   | E03725 | Outlet Protector Net                          | 1 | Oulet                                                                               |
| 25   | E03636 | FAN ASSY                                      | 1 | Assembly ( Fan Casing + Runner + Fan Motor)                                         |
| 26   | E03637 | Fan Unit Feet                                 | 1 |                                                                                     |
| 27   | E03638 | Rubber                                        | 1 | Before Serial Number 4KE12179                                                       |
| 27   | E02060 | RUBBER BUSH                                   | 1 | After Serial Number 4KE12179                                                        |
| 28   | E02688 | CAPILLARY UNIT                                | 1 |                                                                                     |
| 29   | E02031 | FLANGE ASSY                                   | 1 |                                                                                     |
| 30   | E02032 | CAPILLARY                                     | 1 |                                                                                     |
| 31   | E02033 | CONDENSER ASSY                                | 1 |                                                                                     |
| 32   | P27310 | CHECK VALVE                                   | 1 |                                                                                     |
| 33   | E02689 | OIL SEPARATOR                                 | 1 |                                                                                     |
| 34   | E02035 | L TANK                                        | 1 | Assembly                                                                            |
| 35   | E02036 | COMPRESSOR E656DHD-65D2                       | 1 | E656DHD- 65D2                                                                       |
| 36   | P24721 | MAGNETIC CONTACTOR                            | 1 |                                                                                     |
| 37   | P23796 | RESISTOR                                      | 1 |                                                                                     |
| 38   | P23797 | RESISTOR                                      | 1 |                                                                                     |
| 39   | P26062 | RESISTOR                                      | 2 |                                                                                     |
| 40   | E02690 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 40-1 | P24511 | SOLENOID VALVE                                | 1 | Solenoid valve body - SVB                                                           |
| 40-2 | E02080 | HARNESS SVA2                                  | 1 | SVA2 ( Solenoid Valve Coil)                                                         |
| 41   | E02691 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 41-1 | P25246 | SOLENOID VALVE                                | 1 | Solenoid valve body                                                                 |

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                             |   |                                        |
|------|--------|-----------------------------|---|----------------------------------------|
| 41-2 | E02081 | HARNESS SVF                 | 1 | SVF ( Solenoid Valve Coil)             |
| 42   | P26468 | FOUR WAY VALVE              | 1 | Reversing Valve                        |
| 43   | E02039 | HARNESS RVR                 | 1 | RVR ( Reversing Valve Coil)            |
| 44   | E03793 | Reactor                     | 1 | DCL                                    |
| 45   | E01294 | TRANSFORMER                 | 1 | TF                                     |
| 46   | E01873 | MAGNETIC CONTACTOR          | 1 |                                        |
| 47   | E03640 | Fan Adapter                 | 1 |                                        |
| 48   | P27216 | PCB                         | 1 | Printed circuit board 2 - For Inverter |
| 49   | E03336 | Printed Circuit Board       | 1 | Main ( PO052 Assy) ( PCB1)             |
| 50   | P27316 | R.P.P RELAY                 | 1 | Relay phase protection ( 3N~)          |
| 51   | E02042 | INVERTER FIN                | 1 | For Inverter                           |
| 52   | E03780 | VFD                         | 1 | Variable frequency driver              |
| 53   | E01015 | FUSE HOLDER                 | 2 |                                        |
| 54   | E02045 | DRAIN PAN ASSY              | 1 | Assembly                               |
| 55   | E03726 | Bottom Base Assembly        | 1 | Assembly                               |
| 56   | E03653 | Pipe D 1                    | 1 | Compressor discharge pipe 1            |
| 57   | E03727 | E-Box Cover Assy            | 1 | Assembly                               |
| 58   | E03728 | Front Cover Assy            | 1 | Assembly                               |
| 59   | E03729 | L-Back Corner Assy          | 1 | Assembly                               |
| 60   | E03730 | L-Corner Assy               | 1 | Assembly                               |
| 61   | E03731 | L-Cover Assy                | 1 | Assembly                               |
| 62   | E03732 | Inlet Air Frame AssY        | 1 | Assembly                               |
| 63   | E03733 | Outlet Air Frame Assy       | 1 | Assembly                               |
| 64   | E03734 | R-Corner Assy               | 1 | Assembly                               |
| 65   | E03735 | R-Cover Assy                | 2 | For Righth & Back Cover                |
| 66   | E03736 | Upper Cover Assy            | 1 | Assembly                               |
| 67   | E00809 | FUSE                        | 2 |                                        |
| 68   | P19112 | SPACER                      | 4 |                                        |
| 69   | P20985 | PLASTIC MATERIAL            | 6 |                                        |
| 70   | E02012 | CLAMP                       | 2 |                                        |
| 71   | P24729 | Fuse Holder                 | 2 |                                        |
| 72   | P17225 | SPACER                      | 6 |                                        |
| 73   | P21189 | PUSH SPACER                 | 2 |                                        |
| 74   | E01617 | PUSH SPACER                 | 1 |                                        |
| 75   | E01616 | PUSH SPACER                 | 1 |                                        |
| 76   | E02059 | BAND                        | 4 |                                        |
| 77   | E02060 | RUBBER BUSH                 | 4 |                                        |
| 78   | P26098 | PLASTIC MATERIAL            | 3 |                                        |
| 79   | P20986 | PLASTIC MATERIAL            | 3 |                                        |
| 80   | P26474 | THERMISTOR                  | 1 | For Inverter                           |
| 81   | E03737 | R-Back Cover Assy           | 1 | Assembly                               |
| 82   | E02000 | SPECIAL NUT                 | 4 |                                        |
| 83   | E02062 | CONDENSER STAY 1            | 1 |                                        |
| 84   | E02063 | CONDENSER STAY 2            | 1 |                                        |
| 85   | E03723 | Handle                      | 4 |                                        |
| 86   | E03738 | Stop Valve Protection Cover | 1 |                                        |
| 87   | E02065 | FOOT ASSY                   | 1 | Assembly                               |
| 88   | E03027 | FAN DUCT ASSY               | 1 | Assembly                               |
| 89   | E02681 | FS STAY                     | 1 |                                        |
| 90   | E01038 | FLOAT SW                    | 1 |                                        |

# CENTRIFUGAL RASC-10HRNM1E

|     |        |                          |   |                                                                   |
|-----|--------|--------------------------|---|-------------------------------------------------------------------|
| 91  | E01082 | C-HEATER                 | 1 |                                                                   |
| 92  | E02067 | PIPE SC1 UNIT            | 1 | Sub- cooler pipe 1                                                |
| 93  | E02068 | PIPE SC2 UNIT            | 1 | Sub- cooler pipe 2                                                |
| 94  | E02069 | G VALVE ASSY             | 1 | Gas valve assembly                                                |
| 95  | E02070 | L VALVE ASSY             | 1 | Liquid valve assembly                                             |
| 96  | E02072 | PIPE C ASSY              | 1 | Between 4- Way Valve & Heat Exchanger                             |
| 97  | E02074 | PIPE S ASSY              | 1 | Between 4- Way Valve & Compressor Suction                         |
| 98  | E02695 | PIPE E                   | 1 | Between 4- Way Valve & Gas Stop Valve                             |
| 99  | E02076 | L-PIPE 3                 | 1 | Between 4- Way Valve & Liquid Stop Valve                          |
| 100 | E01900 | RUBBER CAP               | 1 |                                                                   |
| 101 | E02082 | RC COVER                 | 1 | Compressor acoustical cover                                       |
| 102 | E02078 | COVER                    | 1 | Compressor cap                                                    |
| 103 | E02699 | PIPE 3 SVF               | 1 | Solenoid valve pipe                                               |
| 104 | E03654 | Pipe D2                  | 1 | Compressor discharge pipe 2                                       |
| 105 | E02700 | BOTTOM PIPE              | 1 | From Oil Separator                                                |
| 106 | E03643 | VFD Cap Stay Assy        | 1 |                                                                   |
| 107 | E03644 | VFD Stay Insulation Assy | 1 |                                                                   |
| 108 | E02972 | DP Grille                | 1 | Drain pan grille                                                  |
| 109 | E03739 | Back Cover R Assy        | 1 |                                                                   |
| 110 | E03740 | Back Cover L Assy        | 1 |                                                                   |
| 111 | E02977 | L Stay Assy              | 1 |                                                                   |
| 112 | E03645 | Fan Motor Unit           | 1 | Assembly ( Fan Casing + Runner + Fan Motor + Insulations + Feets) |
| 113 | E03045 | PIPE D3                  | 1 | Compressor discharge pipe 3                                       |
| 114 | E03646 | Cable Clamp              | 1 |                                                                   |


# CENTRIFUGAL RASC-10HRNM1E

Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT  
ELECTRICAL EQUIPMENT

MODEL: RASC-10HRNM1E



HITACHI

97

EPH-201213G-2B

| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                                               |   |                                                                                     |
|------|--------|-----------------------------------------------|---|-------------------------------------------------------------------------------------|
| 1    | E00705 | TERMINAL BOARD                                | 1 |                                                                                     |
| 2    | E02682 | CORD PS                                       | 1 | PSH ( Pressure Switch High)                                                         |
| 3    | E02683 | HARNESS PC                                    | 1 | PSC ( Pressure Switch Control)                                                      |
| 4    | P24776 | Fuse                                          | 2 | 40A                                                                                 |
| 5    | E03634 | Electrical Box                                | 1 | Assembly ( Components+ Harness+ Steel Plates+ Insulations)                          |
| 6    | P28496 | CAPACITOR                                     | 2 | 4700μ F                                                                             |
| 7    | E02684 | THERMISTOR                                    | 1 | For discharge gas temperature                                                       |
| 8    | E02685 | THERMISTOR                                    | 1 | For outdoor ambient temperature                                                     |
| 9    | E02686 | THERMISTOR                                    | 1 | For evaporating temperature                                                         |
| 10   | E03635 | Acoustial Cover                               | 1 |                                                                                     |
| 11   | P26740 | NOISE FILTER                                  | 1 |  |
| 12   | P27215 | TRANSISTOR M                                  | 1 | For Inverter                                                                        |
| 13   | P27214 | DIODE MODULE                                  | 1 | For Inverter                                                                        |
| 14   | E02024 | EXP. VALVE UNIT                               | 1 |                                                                                     |
| 14-1 | P26009 | COIL FOR EXP. VALVE                           | 1 |                                                                                     |
| 14-2 | P26008 | EXP. VALVE                                    | 1 |                                                                                     |
| 14-3 | P26471 | STRAINER                                      | 2 |                                                                                     |
| 14-4 | E02079 | EXP. VALVE CORD                               | 1 |                                                                                     |
| 15   | P26002 | STOP VALVE (référence du joint seul : P26149) | 1 | Gas Line                                                                            |
| 16   | E01511 | STOP VALVE                                    | 1 | Liquid Line                                                                         |
| 17   | E01160 | CHECK JOINT                                   | 1 | Check joint                                                                         |
| 18   | P21169 | DIST. STRAINER                                | 1 |                                                                                     |
| 19   | P24399 | STRAINER                                      | 1 |                                                                                     |
| 20   | P25036 | FILTRE DETENDEUR                              | 1 |                                                                                     |
| 21   | P13109 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 2                                                            |
| 22   | P17308 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 1                                                            |
| 23   | E03724 | Inlet Protector Net                           | 1 | Inlet                                                                               |
| 24   | E03725 | Outlet Protector Net                          | 1 | Oulet                                                                               |
| 25   | E03636 | FAN ASSY                                      | 1 | Assembly ( Fan Casing + Runner + Fan Motor)                                         |
| 26   | E03637 | Fan Unit Feet                                 | 1 |                                                                                     |
| 27   | E03638 | Rubber                                        | 1 | Before Serial Number 4KE12179                                                       |
| 27   | E02060 | RUBBER BUSH                                   | 1 | After Serial Number 4KE12179                                                        |
| 28   | E02688 | CAPILLARY UNIT                                | 1 |                                                                                     |
| 29   | E02031 | FLANGE ASSY                                   | 1 |                                                                                     |
| 30   | E02032 | CAPILLARY                                     | 1 |                                                                                     |
| 31   | E02033 | CONDENSER ASSY                                | 1 |                                                                                     |
| 32   | P27310 | CHECK VALVE                                   | 1 |                                                                                     |
| 33   | E02689 | OIL SEPARATOR                                 | 1 |                                                                                     |
| 34   | E02035 | L TANK                                        | 1 | Assembly                                                                            |
| 35   | E02036 | COMPRESSOR E656DHD-65D2                       | 1 | E656DHD- 65D2                                                                       |
| 36   | P24721 | MAGNETIC CONTACTOR                            | 1 |                                                                                     |
| 37   | P23796 | RESISTOR                                      | 1 |                                                                                     |
| 38   | P23797 | RESISTOR                                      | 1 |                                                                                     |
| 39   | P26062 | RESISTOR                                      | 2 |                                                                                     |
| 40   | E02690 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 40-1 | P24511 | SOLENOID VALVE                                | 1 | Solenoid valve body - SVB                                                           |
| 40-2 | E02080 | HARNESS SVA2                                  | 1 | SVA2 ( Solenoid Valve Coil)                                                         |
| 41   | E02691 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 41-1 | P25246 | SOLENOID VALVE                                | 1 | Solenoid valve body                                                                 |

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                             |   |                                        |
|------|--------|-----------------------------|---|----------------------------------------|
| 41-2 | E02081 | HARNESS SVF                 | 1 | SVF ( Solenoid Valve Coil)             |
| 42   | P26468 | FOUR WAY VALVE              | 1 | Reversing Valve                        |
| 43   | E02039 | HARNESS RVR                 | 1 | RVR ( Reversing Valve Coil)            |
| 44   | E03793 | Reactor                     | 1 | DCL                                    |
| 45   | E01294 | TRANSFORMER                 | 1 | TF                                     |
| 46   | E01873 | MAGNETIC CONTACTOR          | 1 |                                        |
| 47   | E03640 | Fan Adapter                 | 1 |                                        |
| 48   | P27216 | PCB                         | 1 | Printed circuit board 2 - For Inverter |
| 49   | E03336 | Printed Circuit Board       | 1 | Main ( PO052 Assy) ( PCB1)             |
| 50   | P27316 | R.P.P RELAY                 | 1 | Relay phase protection ( 3N~)          |
| 51   | E02042 | INVERTER FIN                | 1 | For Inverter                           |
| 52   | E03780 | VFD                         | 1 | Variable frequency driver              |
| 53   | E01015 | FUSE HOLDER                 | 2 |                                        |
| 54   | E02045 | DRAIN PAN ASSY              | 1 | Assembly                               |
| 55   | E03726 | Bottom Base Assembly        | 1 | Assembly                               |
| 56   | E03653 | Pipe D 1                    | 1 | Compressor discharge pipe 1            |
| 57   | E03727 | E-Box Cover Assy            | 1 | Assembly                               |
| 58   | E03728 | Front Cover Assy            | 1 | Assembly                               |
| 59   | E03729 | L-Back Corner Assy          | 1 | Assembly                               |
| 60   | E03730 | L-Corner Assy               | 1 | Assembly                               |
| 61   | E03731 | L-Cover Assy                | 1 | Assembly                               |
| 62   | E03732 | Inlet Air Frame AssY        | 1 | Assembly                               |
| 63   | E03733 | Outlet Air Frame Assy       | 1 | Assembly                               |
| 64   | E03734 | R-Corner Assy               | 1 | Assembly                               |
| 65   | E03735 | R-Cover Assy                | 2 | For Righth & Back Cover                |
| 66   | E03736 | Upper Cover Assy            | 1 | Assembly                               |
| 67   | E00809 | FUSE                        | 2 |                                        |
| 68   | P19112 | SPACER                      | 4 |                                        |
| 69   | P20985 | PLASTIC MATERIAL            | 6 |                                        |
| 70   | E02012 | CLAMP                       | 2 |                                        |
| 71   | P24729 | Fuse Holder                 | 2 |                                        |
| 72   | P17225 | SPACER                      | 6 |                                        |
| 73   | P21189 | PUSH SPACER                 | 2 |                                        |
| 74   | E01617 | PUSH SPACER                 | 1 |                                        |
| 75   | E01616 | PUSH SPACER                 | 1 |                                        |
| 76   | E02059 | BAND                        | 4 |                                        |
| 77   | E02060 | RUBBER BUSH                 | 4 |                                        |
| 78   | P26098 | PLASTIC MATERIAL            | 3 |                                        |
| 79   | P20986 | PLASTIC MATERIAL            | 3 |                                        |
| 80   | P26474 | THERMISTOR                  | 1 | For Inverter                           |
| 81   | E03737 | R-Back Cover Assy           | 1 | Assembly                               |
| 82   | E02000 | SPECIAL NUT                 | 4 |                                        |
| 83   | E02062 | CONDENSER STAY 1            | 1 |                                        |
| 84   | E02063 | CONDENSER STAY 2            | 1 |                                        |
| 85   | E03723 | Handle                      | 4 |                                        |
| 86   | E03738 | Stop Valve Protection Cover | 1 |                                        |
| 87   | E02065 | FOOT ASSY                   | 1 | Assembly                               |
| 88   | E03027 | FAN DUCT ASSY               | 1 | Assembly                               |
| 89   | E02681 | FS STAY                     | 1 |                                        |
| 90   | E01038 | FLOAT SW                    | 1 |                                        |

# CENTRIFUGAL RASC-10HRNM1E


|     |        |                          |   |                                                                   |
|-----|--------|--------------------------|---|-------------------------------------------------------------------|
| 91  | E01082 | C-HEATER                 | 1 |                                                                   |
| 92  | E02067 | PIPE SC1 UNIT            | 1 | Sub- cooler pipe 1                                                |
| 93  | E02068 | PIPE SC2 UNIT            | 1 | Sub- cooler pipe 2                                                |
| 94  | E02069 | G VALVE ASSY             | 1 | Gas valve assembly                                                |
| 95  | E02070 | L VALVE ASSY             | 1 | Liquid valve assembly                                             |
| 96  | E02072 | PIPE C ASSY              | 1 | Between 4- Way Valve & Heat Exchanger                             |
| 97  | E02074 | PIPE S ASSY              | 1 | Between 4- Way Valve & Compressor Suction                         |
| 98  | E02695 | PIPE E                   | 1 | Between 4- Way Valve & Gas Stop Valve                             |
| 99  | E02076 | L-PIPE 3                 | 1 | Between 4- Way Valve & Liquid Stop Valve                          |
| 100 | E01900 | RUBBER CAP               | 1 |                                                                   |
| 101 | E02082 | RC COVER                 | 1 | Compressor acoustical cover                                       |
| 102 | E02078 | COVER                    | 1 | Compressor cap                                                    |
| 103 | E02699 | PIPE 3 SVF               | 1 | Solenoid valve pipe                                               |
| 104 | E03654 | Pipe D2                  | 1 | Compressor discharge pipe 2                                       |
| 105 | E02700 | BOTTOM PIPE              | 1 | From Oil Separator                                                |
| 106 | E03643 | VFD Cap Stay Assy        | 1 |                                                                   |
| 107 | E03644 | VFD Stay Insulation Assy | 1 |                                                                   |
| 108 | E02972 | DP Grille                | 1 | Drain pan grille                                                  |
| 109 | E03739 | Back Cover R Assy        | 1 |                                                                   |
| 110 | E03740 | Back Cover L Assy        | 1 |                                                                   |
| 111 | E02977 | L Stay Assy              | 1 |                                                                   |
| 112 | E03645 | Fan Motor Unit           | 1 | Assembly ( Fan Casing + Runner + Fan Motor + Insulations + Feets) |
| 113 | E03045 | PIPE D3                  | 1 | Compressor discharge pipe 3                                       |
| 114 | E03646 | Cable Clamp              | 1 |                                                                   |



# CENTRIFUGAL RASC-10HRNM1E

Pièces détachées

Main view



HITACHI

777

EPH-201213G-38

| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                                               |   |                                                                                     |
|------|--------|-----------------------------------------------|---|-------------------------------------------------------------------------------------|
| 1    | E00705 | TERMINAL BOARD                                | 1 |                                                                                     |
| 2    | E02682 | CORD PS                                       | 1 | PSH ( Pressure Switch High)                                                         |
| 3    | E02683 | HARNESS PC                                    | 1 | PSC ( Pressure Switch Control)                                                      |
| 4    | P24776 | Fuse                                          | 2 | 40A                                                                                 |
| 5    | E03634 | Electrical Box                                | 1 | Assembly ( Components+ Harness+ Steel Plates+ Insulations)                          |
| 6    | P28496 | CAPACITOR                                     | 2 | 4700μ F                                                                             |
| 7    | E02684 | THERMISTOR                                    | 1 | For discharge gas temperature                                                       |
| 8    | E02685 | THERMISTOR                                    | 1 | For outdoor ambient temperature                                                     |
| 9    | E02686 | THERMISTOR                                    | 1 | For evaporating temperature                                                         |
| 10   | E03635 | Acoustial Cover                               | 1 |                                                                                     |
| 11   | P26740 | NOISE FILTER                                  | 1 |  |
| 12   | P27215 | TRANSISTOR M                                  | 1 | For Inverter                                                                        |
| 13   | P27214 | DIODE MODULE                                  | 1 | For Inverter                                                                        |
| 14   | E02024 | EXP. VALVE UNIT                               | 1 |                                                                                     |
| 14-1 | P26009 | COIL FOR EXP. VALVE                           | 1 |                                                                                     |
| 14-2 | P26008 | EXP. VALVE                                    | 1 |                                                                                     |
| 14-3 | P26471 | STRAINER                                      | 2 |                                                                                     |
| 14-4 | E02079 | EXP. VALVE CORD                               | 1 |                                                                                     |
| 15   | P26002 | STOP VALVE (référence du joint seul : P26149) | 1 | Gas Line                                                                            |
| 16   | E01511 | STOP VALVE                                    | 1 | Liquid Line                                                                         |
| 17   | E01160 | CHECK JOINT                                   | 1 | Check joint                                                                         |
| 18   | P21169 | DIST. STRAINER                                | 1 |                                                                                     |
| 19   | P24399 | STRAINER                                      | 1 |                                                                                     |
| 20   | P25036 | FILTRE DETENDEUR                              | 1 |                                                                                     |
| 21   | P13109 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 2                                                            |
| 22   | P17308 | VIBRATION ABSORBER                            | 4 | Vibration proof rubber 1                                                            |
| 23   | E03724 | Inlet Protector Net                           | 1 | Inlet                                                                               |
| 24   | E03725 | Outlet Protector Net                          | 1 | Oulet                                                                               |
| 25   | E03636 | FAN ASSY                                      | 1 | Assembly ( Fan Casing + Runner + Fan Motor)                                         |
| 26   | E03637 | Fan Unit Feet                                 | 1 |                                                                                     |
| 27   | E03638 | Rubber                                        | 1 | Before Serial Number 4KE12179                                                       |
| 27   | E02060 | RUBBER BUSH                                   | 1 | After Serial Number 4KE12179                                                        |
| 28   | E02688 | CAPILLARY UNIT                                | 1 |                                                                                     |
| 29   | E02031 | FLANGE ASSY                                   | 1 |                                                                                     |
| 30   | E02032 | CAPILLARY                                     | 1 |                                                                                     |
| 31   | E02033 | CONDENSER ASSY                                | 1 |                                                                                     |
| 32   | P27310 | CHECK VALVE                                   | 1 |                                                                                     |
| 33   | E02689 | OIL SEPARATOR                                 | 1 |                                                                                     |
| 34   | E02035 | L TANK                                        | 1 | Assembly                                                                            |
| 35   | E02036 | COMPRESSOR E656DHD-65D2                       | 1 | E656DHD- 65D2                                                                       |
| 36   | P24721 | MAGNETIC CONTACTOR                            | 1 |                                                                                     |
| 37   | P23796 | RESISTOR                                      | 1 |                                                                                     |
| 38   | P23797 | RESISTOR                                      | 1 |                                                                                     |
| 39   | P26062 | RESISTOR                                      | 2 |                                                                                     |
| 40   | E02690 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 40-1 | P24511 | SOLENOID VALVE                                | 1 | Solenoid valve body - SVB                                                           |
| 40-2 | E02080 | HARNESS SVA2                                  | 1 | SVA2 ( Solenoid Valve Coil)                                                         |
| 41   | E02691 | SVB ASSY                                      | 1 | Solenoid valve assembly                                                             |
| 41-1 | P25246 | SOLENOID VALVE                                | 1 | Solenoid valve body                                                                 |

# CENTRIFUGAL RASC-10HRNM1E

|      |        |                             |   |                                        |
|------|--------|-----------------------------|---|----------------------------------------|
| 41-2 | E02081 | HARNESS SVF                 | 1 | SVF ( Solenoid Valve Coil)             |
| 42   | P26468 | FOUR WAY VALVE              | 1 | Reversing Valve                        |
| 43   | E02039 | HARNESS RVR                 | 1 | RVR ( Reversing Valve Coil)            |
| 44   | E03793 | Reactor                     | 1 | DCL                                    |
| 45   | E01294 | TRANSFORMER                 | 1 | TF                                     |
| 46   | E01873 | MAGNETIC CONTACTOR          | 1 |                                        |
| 47   | E03640 | Fan Adapter                 | 1 |                                        |
| 48   | P27216 | PCB                         | 1 | Printed circuit board 2 - For Inverter |
| 49   | E03336 | Printed Circuit Board       | 1 | Main ( PO052 Assy) ( PCB1)             |
| 50   | P27316 | R.P.P RELAY                 | 1 | Relay phase protection ( 3N~)          |
| 51   | E02042 | INVERTER FIN                | 1 | For Inverter                           |
| 52   | E03780 | VFD                         | 1 | Variable frequency driver              |
| 53   | E01015 | FUSE HOLDER                 | 2 |                                        |
| 54   | E02045 | DRAIN PAN ASSY              | 1 | Assembly                               |
| 55   | E03726 | Bottom Base Assembly        | 1 | Assembly                               |
| 56   | E03653 | Pipe D 1                    | 1 | Compressor discharge pipe 1            |
| 57   | E03727 | E-Box Cover Assy            | 1 | Assembly                               |
| 58   | E03728 | Front Cover Assy            | 1 | Assembly                               |
| 59   | E03729 | L-Back Corner Assy          | 1 | Assembly                               |
| 60   | E03730 | L-Corner Assy               | 1 | Assembly                               |
| 61   | E03731 | L-Cover Assy                | 1 | Assembly                               |
| 62   | E03732 | Inlet Air Frame AssY        | 1 | Assembly                               |
| 63   | E03733 | Outlet Air Frame Assy       | 1 | Assembly                               |
| 64   | E03734 | R-Corner Assy               | 1 | Assembly                               |
| 65   | E03735 | R-Cover Assy                | 2 | For Righth & Back Cover                |
| 66   | E03736 | Upper Cover Assy            | 1 | Assembly                               |
| 67   | E00809 | FUSE                        | 2 |                                        |
| 68   | P19112 | SPACER                      | 4 |                                        |
| 69   | P20985 | PLASTIC MATERIAL            | 6 |                                        |
| 70   | E02012 | CLAMP                       | 2 |                                        |
| 71   | P24729 | Fuse Holder                 | 2 |                                        |
| 72   | P17225 | SPACER                      | 6 |                                        |
| 73   | P21189 | PUSH SPACER                 | 2 |                                        |
| 74   | E01617 | PUSH SPACER                 | 1 |                                        |
| 75   | E01616 | PUSH SPACER                 | 1 |                                        |
| 76   | E02059 | BAND                        | 4 |                                        |
| 77   | E02060 | RUBBER BUSH                 | 4 |                                        |
| 78   | P26098 | PLASTIC MATERIAL            | 3 |                                        |
| 79   | P20986 | PLASTIC MATERIAL            | 3 |                                        |
| 80   | P26474 | THERMISTOR                  | 1 | For Inverter                           |
| 81   | E03737 | R-Back Cover Assy           | 1 | Assembly                               |
| 82   | E02000 | SPECIAL NUT                 | 4 |                                        |
| 83   | E02062 | CONDENSER STAY 1            | 1 |                                        |
| 84   | E02063 | CONDENSER STAY 2            | 1 |                                        |
| 85   | E03723 | Handle                      | 4 |                                        |
| 86   | E03738 | Stop Valve Protection Cover | 1 |                                        |
| 87   | E02065 | FOOT ASSY                   | 1 | Assembly                               |
| 88   | E03027 | FAN DUCT ASSY               | 1 | Assembly                               |
| 89   | E02681 | FS STAY                     | 1 |                                        |
| 90   | E01038 | FLOAT SW                    | 1 |                                        |

# CENTRIFUGAL RASC-10HRNM1E

|     |        |                          |   |                                                                   |
|-----|--------|--------------------------|---|-------------------------------------------------------------------|
| 91  | E01082 | C-HEATER                 | 1 |                                                                   |
| 92  | E02067 | PIPE SC1 UNIT            | 1 | Sub- cooler pipe 1                                                |
| 93  | E02068 | PIPE SC2 UNIT            | 1 | Sub- cooler pipe 2                                                |
| 94  | E02069 | G VALVE ASSY             | 1 | Gas valve assembly                                                |
| 95  | E02070 | L VALVE ASSY             | 1 | Liquid valve assembly                                             |
| 96  | E02072 | PIPE C ASSY              | 1 | Between 4- Way Valve & Heat Exchanger                             |
| 97  | E02074 | PIPE S ASSY              | 1 | Between 4- Way Valve & Compressor Suction                         |
| 98  | E02695 | PIPE E                   | 1 | Between 4- Way Valve & Gas Stop Valve                             |
| 99  | E02076 | L-PIPE 3                 | 1 | Between 4- Way Valve & Liquid Stop Valve                          |
| 100 | E01900 | RUBBER CAP               | 1 |                                                                   |
| 101 | E02082 | RC COVER                 | 1 | Compressor acoustical cover                                       |
| 102 | E02078 | COVER                    | 1 | Compressor cap                                                    |
| 103 | E02699 | PIPE 3 SVF               | 1 | Solenoid valve pipe                                               |
| 104 | E03654 | Pipe D2                  | 1 | Compressor discharge pipe 2                                       |
| 105 | E02700 | BOTTOM PIPE              | 1 | From Oil Separator                                                |
| 106 | E03643 | VFD Cap Stay Assy        | 1 |                                                                   |
| 107 | E03644 | VFD Stay Insulation Assy | 1 |                                                                   |
| 108 | E02972 | DP Grille                | 1 | Drain pan grille                                                  |
| 109 | E03739 | Back Cover R Assy        | 1 |                                                                   |
| 110 | E03740 | Back Cover L Assy        | 1 |                                                                   |
| 111 | E02977 | L Stay Assy              | 1 |                                                                   |
| 112 | E03645 | Fan Motor Unit           | 1 | Assembly ( Fan Casing + Runner + Fan Motor + Insulations + Feets) |
| 113 | E03045 | PIPE D3                  | 1 | Compressor discharge pipe 3                                       |
| 114 | E03646 | Cable Clamp              | 1 |                                                                   |