


CENTRIFUGAL RASC-5HVRNME

Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT
CABINET AND FAN



HITACHI

0/13

EPH-201113D-1B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CENTRIFUGAL RASC-5HVRNME

1	E01818	TERMINAL BOARD	1	
2	E01958	HARNESS PS	1	PSH (Pressure Switch High)
3	E01959	PSC	1	PSC (Pressure Switch Control)
4	P24728	FUSE 50A	1	50A
5	E01960	FUSE	1	10A
6	E01961	ELECTRICAL BOX	1	Assembly (Components + Harness + Steel Plates)
7	P22531	CAPACITOR	1	30μ F
8	P22520	THERMISTOR - aire	1	TA
9	P23507	THERMISTOR	1	TE
10	P22573	THERMISTOR	1	TD
11	P26446	NOISE FILTER	1	
12	E01963	evo assy	1	
12-1	P24691	EXP. VALVE	1	
12-2	E02669	EXPV COIL	1	
12-3	P25037	STRAINER	2	
13	E01964	REFRIGERATION COMPONENT	1	Gas Line
14	E01525	STOP VALVE	1	Liquid Line
15	P25044	CHECK JOINT	1	
16	P24398	STRAINER	1	
17	P17308	VIBRATION ABSORBER	4	
18	P13109	VIBRATION ABSORBER	4	
19	E01965	PROTECTOR NET 1	1	Inlet
20	E01966	PROTECTOR NET 2	1	Outlet
21	E01846	FAN CASING ASSY L (Runner+Casing)	1	Fan Casing + Runner (left)
22	E01845	FAN CASING ASSY R (Runner+Casing)	1	Fan Casing + Runner (right)
23	E01967	FAN UNIT	1	Assembly
24	E01969	CONDENSER	1	Assembly
25	E01971	L-TANK	1	Assembly
26	E01973	COMPRESSOR E405ALD-36A2	1	E405ALD- 36A2
27	E01974	FAN MOTOR	1	DC 950W, 4P
28	P24721	MAGNETIC CONTACTOR	1	
29	E01976	SV ASSY	1	
29-1	P25246	SOLENOID VALVE	1	Solenoid Valve
29-2	E02017	COIL HARNESS 20	1	SVA (Solenoid Valve Coil)
30	P26564	OIL HEATER	2	
31	P26337	4-WAY VALVE	1	Reversing Valve
32	E01978	COIL HARNESS 20	1	RVR (Reversing Valve Coil)
33	E01294	TRANSFORMER	1	TF
34	E01828	REACTOR	1	DCL
35	E01979	PRINTED CIRCUIT BOARD	1	Main (PO052 Assy)
36	P29545	INVERTER FIN ASSY	1	DIP IPM 25A (PV051 Assy)
37	E01502	SSR	1	
38	E01980	RADATION FIN	1	
39	E00731	FLOAT SW	1	
40	E03033	DRAIN PAN UNIT	1	
41	E03036	SIDE COVER 1 ASSY	1	Assembly
42	E02671	SIDE COVER 3 ASSY	1	Assembly
43	E03053	SIDE COVER 2 ASSY	1	Assembly
44	E02673	E-BOX COVER ASSY	1	Assembly
45	E02674	U COVER 2 UNIT	1	Assembly

CENTRIFUGAL RASC-5HVRNME


46	E02675	FAN COVER UNIT	1	Assembly
47	E02676	SIDE STAY COVER ASSY	1	Assembly
48	E02677	VALVE COVER 1 ASSY	1	Assembly
49	E02678	VALVE COVER 2 ASSY	1	Assembly
50	E01991	WIRING COVER	1	
51	E03034	CORNER COVER ASSY	1	Assembly
52	E01993	B-BASE ASSY	1	Assembly
53	E01994	U COVER 1 ASSY	1	Assembly
54	E01995	SUCTION COVER 1 ASSY	1	Assembly
55	E03035	D-COVER ASSY	1	Assembly
56	E01997	COMP BASE	1	
57	P24729	Fuse Holder	1	
58	P24391	HANDLE	2	
59	E01999	RUBBER BUSHING	2	
60	E02000	SPECIAL NUT	4	
61	P20984	PLASTIC MATERIAL	2	
62	E02001	FAN PARTITION PLATE	1	
63	P20985	PLASTIC MATERIAL	4	
64	E02002	CAPILLARY ASSY	1	
65	E02003	SV STAY	1	
66	E02680	SIDE PARTITION PLATE	1	
67	E02681	FS STAY	1	
68	E02006	FUSE HOLDER	1	
69	E02007	PIPE ASSY	1	
70	E02008	CASINGS STAY	1	
71	E02009	ACOUSTICAL COVER 1	1	
72	E02010	FAN PARTITION ASSY	1	
73	E02011	MOTOR BASE	1	
74	E02012	CLAMP	2	
75	P17225	SPACER	6	
76	P21189	PUSH SPACER	2	
77	E01611	BRACKET	2	
78	E02013	ACOUSTICAL COVER 2	2	
79	E02014	FAN STAY ASSY	1	Assembly
80	E02015	L BASE	1	
81	E02016	SUSPENSION BASE	2	

CENTRIFUGAL RASC-5HVRNME


Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT
REFRIGERANT CYCLE



MODEL: RASC-5HVRNME



HITACHI

9/13

EPH-201113D-2B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CENTRIFUGAL RASC-5HVRNME

1	E01818	TERMINAL BOARD	1	
2	E01958	HARNESS PS	1	PSH (Pressure Switch High)
3	E01959	PSC	1	PSC (Pressure Switch Control)
4	P24728	FUSE 50A	1	50A
5	E01960	FUSE	1	10A
6	E01961	ELECTRICAL BOX	1	Assembly (Components + Harness + Steel Plates)
7	P22531	CAPACITOR	1	30μ F
8	P22520	THERMISTOR - aire	1	TA
9	P23507	THERMISTOR	1	TE
10	P22573	THERMISTOR	1	TD
11	P26446	NOISE FILTER	1	
12	E01963	evo assy	1	
12-1	P24691	EXP. VALVE	1	
12-2	E02669	EXPV COIL	1	
12-3	P25037	STRAINER	2	
13	E01964	REFRIGERATION COMPONENT	1	Gas Line
14	E01525	STOP VALVE	1	Liquid Line
15	P25044	CHECK JOINT	1	
16	P24398	STRAINER	1	
17	P17308	VIBRATION ABSORBER	4	
18	P13109	VIBRATION ABSORBER	4	
19	E01965	PROTECTOR NET 1	1	Inlet
20	E01966	PROTECTOR NET 2	1	Outlet
21	E01846	FAN CASING ASSY L (Runner+Casing)	1	Fan Casing + Runner (left)
22	E01845	FAN CASING ASSY R (Runner+Casing)	1	Fan Casing + Runner (right)
23	E01967	FAN UNIT	1	Assembly
24	E01969	CONDENSER	1	Assembly
25	E01971	L-TANK	1	Assembly
26	E01973	COMPRESSOR E405ALD-36A2	1	E405ALD- 36A2
27	E01974	FAN MOTOR	1	DC 950W, 4P
28	P24721	MAGNETIC CONTACTOR	1	
29	E01976	SV ASSY	1	
29-1	P25246	SOLENOID VALVE	1	Solenoid Valve
29-2	E02017	COIL HARNESS 20	1	SVA (Solenoid Valve Coil)
30	P26564	OIL HEATER	2	
31	P26337	4-WAY VALVE	1	Reversing Valve
32	E01978	COIL HARNESS 20	1	RVR (Reversing Valve Coil)
33	E01294	TRANSFORMER	1	TF
34	E01828	REACTOR	1	DCL
35	E01979	PRINTED CIRCUIT BOARD	1	Main (PO052 Assy)
36	P29545	INVERTER FIN ASSY	1	DIP IPM 25A (PV051 Assy)
37	E01502	SSR	1	
38	E01980	RADATION FIN	1	
39	E00731	FLOAT SW	1	
40	E03033	DRAIN PAN UNIT	1	
41	E03036	SIDE COVER 1 ASSY	1	Assembly
42	E02671	SIDE COVER 3 ASSY	1	Assembly
43	E03053	SIDE COVER 2 ASSY	1	Assembly
44	E02673	E-BOX COVER ASSY	1	Assembly
45	E02674	U COVER 2 UNIT	1	Assembly

CENTRIFUGAL RASC-5HVRNME


46	E02675	FAN COVER UNIT	1	Assembly
47	E02676	SIDE STAY COVER ASSY	1	Assembly
48	E02677	VALVE COVER 1 ASSY	1	Assembly
49	E02678	VALVE COVER 2 ASSY	1	Assembly
50	E01991	WIRING COVER	1	
51	E03034	CORNER COVER ASSY	1	Assembly
52	E01993	B-BASE ASSY	1	Assembly
53	E01994	U COVER 1 ASSY	1	Assembly
54	E01995	SUCTION COVER 1 ASSY	1	Assembly
55	E03035	D-COVER ASSY	1	Assembly
56	E01997	COMP BASE	1	
57	P24729	Fuse Holder	1	
58	P24391	HANDLE	2	
59	E01999	RUBBER BUSHING	2	
60	E02000	SPECIAL NUT	4	
61	P20984	PLASTIC MATERIAL	2	
62	E02001	FAN PARTITION PLATE	1	
63	P20985	PLASTIC MATERIAL	4	
64	E02002	CAPILLARY ASSY	1	
65	E02003	SV STAY	1	
66	E02680	SIDE PARTITION PLATE	1	
67	E02681	FS STAY	1	
68	E02006	FUSE HOLDER	1	
69	E02007	PIPE ASSY	1	
70	E02008	CASINGS STAY	1	
71	E02009	ACOUSTICAL COVER 1	1	
72	E02010	FAN PARTITION ASSY	1	
73	E02011	MOTOR BASE	1	
74	E02012	CLAMP	2	
75	P17225	SPACER	6	
76	P21189	PUSH SPACER	2	
77	E01611	BRACKET	2	
78	E02013	ACOUSTICAL COVER 2	2	
79	E02014	FAN STAY ASSY	1	Assembly
80	E02015	L BASE	1	
81	E02016	SUSPENSION BASE	2	

CENTRIFUGAL RASC-5HVRNME


Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT
ELECTRICAL EQUIPMENT



MODEL: RASC-5HVRNME



HITACHI

1013

EPH-201113D-3B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CENTRIFUGAL RASC-5HVRNME

1	E01818	TERMINAL BOARD	1	
2	E01958	HARNESS PS	1	PSH (Pressure Switch High)
3	E01959	PSC	1	PSC (Pressure Switch Control)
4	P24728	FUSE 50A	1	50A
5	E01960	FUSE	1	10A
6	E01961	ELECTRICAL BOX	1	Assembly (Components + Harness + Steel Plates)
7	P22531	CAPACITOR	1	30μ F
8	P22520	THERMISTOR - aire	1	TA
9	P23507	THERMISTOR	1	TE
10	P22573	THERMISTOR	1	TD
11	P26446	NOISE FILTER	1	
12	E01963	evo assy	1	
12-1	P24691	EXP. VALVE	1	
12-2	E02669	EXPV COIL	1	
12-3	P25037	STRAINER	2	
13	E01964	REFRIGERATION COMPONENT	1	Gas Line
14	E01525	STOP VALVE	1	Liquid Line
15	P25044	CHECK JOINT	1	
16	P24398	STRAINER	1	
17	P17308	VIBRATION ABSORBER	4	
18	P13109	VIBRATION ABSORBER	4	
19	E01965	PROTECTOR NET 1	1	Inlet
20	E01966	PROTECTOR NET 2	1	Outlet
21	E01846	FAN CASING ASSY L (Runner+Casing)	1	Fan Casing + Runner (left)
22	E01845	FAN CASING ASSY R (Runner+Casing)	1	Fan Casing + Runner (right)
23	E01967	FAN UNIT	1	Assembly
24	E01969	CONDENSER	1	Assembly
25	E01971	L-TANK	1	Assembly
26	E01973	COMPRESSOR E405ALD-36A2	1	E405ALD- 36A2
27	E01974	FAN MOTOR	1	DC 950W, 4P
28	P24721	MAGNETIC CONTACTOR	1	
29	E01976	SV ASSY	1	
29-1	P25246	SOLENOID VALVE	1	Solenoid Valve
29-2	E02017	COIL HARNESS 20	1	SVA (Solenoid Valve Coil)
30	P26564	OIL HEATER	2	
31	P26337	4-WAY VALVE	1	Reversing Valve
32	E01978	COIL HARNESS 20	1	RVR (Reversing Valve Coil)
33	E01294	TRANSFORMER	1	TF
34	E01828	REACTOR	1	DCL
35	E01979	PRINTED CIRCUIT BOARD	1	Main (PO052 Assy)
36	P29545	INVERTER FIN ASSY	1	DIP IPM 25A (PV051 Assy)
37	E01502	SSR	1	
38	E01980	RADATION FIN	1	
39	E00731	FLOAT SW	1	
40	E03033	DRAIN PAN UNIT	1	
41	E03036	SIDE COVER 1 ASSY	1	Assembly
42	E02671	SIDE COVER 3 ASSY	1	Assembly
43	E03053	SIDE COVER 2 ASSY	1	Assembly
44	E02673	E-BOX COVER ASSY	1	Assembly
45	E02674	U COVER 2 UNIT	1	Assembly

CENTRIFUGAL RASC-5HVRNME

46	E02675	FAN COVER UNIT	1	Assembly
47	E02676	SIDE STAY COVER ASSY	1	Assembly
48	E02677	VALVE COVER 1 ASSY	1	Assembly
49	E02678	VALVE COVER 2 ASSY	1	Assembly
50	E01991	WIRING COVER	1	
51	E03034	CORNER COVER ASSY	1	Assembly
52	E01993	B-BASE ASSY	1	Assembly
53	E01994	U COVER 1 ASSY	1	Assembly
54	E01995	SUCTION COVER 1 ASSY	1	Assembly
55	E03035	D-COVER ASSY	1	Assembly
56	E01997	COMP BASE	1	
57	P24729	Fuse Holder	1	
58	P24391	HANDLE	2	
59	E01999	RUBBER BUSHING	2	
60	E02000	SPECIAL NUT	4	
61	P20984	PLASTIC MATERIAL	2	
62	E02001	FAN PARTITION PLATE	1	
63	P20985	PLASTIC MATERIAL	4	
64	E02002	CAPILLARY ASSY	1	
65	E02003	SV STAY	1	
66	E02680	SIDE PARTITION PLATE	1	
67	E02681	FS STAY	1	
68	E02006	FUSE HOLDER	1	
69	E02007	PIPE ASSY	1	
70	E02008	CASINGS STAY	1	
71	E02009	ACOUSTICAL COVER 1	1	
72	E02010	FAN PARTITION ASSY	1	
73	E02011	MOTOR BASE	1	
74	E02012	CLAMP	2	
75	P17225	SPACER	6	
76	P21189	PUSH SPACER	2	
77	E01611	BRACKET	2	
78	E02013	ACOUSTICAL COVER 2	2	
79	E02014	FAN STAY ASSY	1	Assembly
80	E02015	L BASE	1	
81	E02016	SUSPENSION BASE	2	