


REFRIGERANT CYCLE

Model: RAS-10FXNE
RAS-12FXNE



HITACHI

PAGE 5/7

EPN-200519F-2B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

S2ET FREE RAS-10FXNE


U01A	P25043	High Pressure Switch	2	HIGH PRESSURE
U01B	P26013	P-SENSOR	1	PD
U01C	P26014	P-SENSOR	1	PS
U04A	E00810	FUSE	4	20A
U04B	E01223	FUSE	1	12. 5A
U14A	P23970	CAPACITOR	2	2700µ F
U14B	E01627	CAPACITOR	1	1800µ F
U15A	P23508	THERMISTOR	1	TD1 (for Inverter compressor)
U15B	P22522	THERMISTOR	1	TD2 (for fixed-speed compressor)
U15C	E01420	THERMISTOR	1	TE1
U15D	P22520	THERMISTOR - aire	1	TA
U15E	E01421	THERMISTOR TE2	1	TE2
U21A	P26007	EXPANSION VALVE	1	
U21B	P26009	COIL FOR EXP. VALVE	1	
U21C	P26008	EXP. VALVE	2	
U21D	E01429	COIL FOR EXPANSION VALVE	1	
U21E	E01369	COIL FOR EXPANSION VALVE	1	
U27A	P26001	STOP VALVE	1	
U27B	P26002	STOP VALVE (référence du joint seul : P26149)	1	
U27C	P26249	STOP VALVE	1	LIQUID 3/8"
U27C	E01525	STOP VALVE	1	LIQUID 3/8"
U28A	P25044	CHECK JOINT	3	
U28B	P26292	CHECK JOINT	2	
U30A	P24399	STRAINER	2	
U30B	P16943	STRAINER	2	
U30C	P21169	DIST. STRAINER	2	
U30D	P25036	FILTRE DETENDEUR	1	
U30E	P24401	STRAINER	4	
U30F	P25037	STRAINER	1	
U32A	P17308	VIBRATION ABSORBER	8	
U32B	P13109	VIBRATION ABSORBER	6	
U34A	P24215	AIR GRILLE	1	OUTLET
U34B	P26054	AIR GRILLE	1	INLET
U34B	E01636	PROTECTOR NET	1	INLET
U40A	E01423	CONDENSER ASSY	1	
U40B	P26502	PLATE HEAT EXCHANGER	1	
U42A	P25439	CHECK VALVE	1	
U42B	P26503	CHECK VALVE	1	
U42C	P27310	CHECK VALVE	3	
U51	P26090	PROPELLER FAN	1	[To Translate : EN =]
U55	E01496	OIL SEPARATOR	1	
U58	E01497	L TANK	1	
U62A	P24778	NOISE FILTER	1	Before serial n° 4HE11605
U62A	P26740	NOISE FILTER	1	After serial n° 4HE11605
U62B	P23798	NOISE FILTER	1	[To Translate : EN =]
U65A	P19112	SPACER	16	[To Translate : EN =]
U65B	E00738	PUSH SPACER	2	[To Translate : EN =]
U70A	06931128	COMPRESSOR E405AHD-36D2Y	1	FOR INVERTER (E405AHD-36D2Y)
U70B	06953520	COMPRESSOR E605DH-59D2Y	1	(E605DH- 59D2Y)
U71	P26031	MOTOR	1	0. 81KW

S2ET FREE RAS-10FXNE

U72A	P24774	MAGNETIC CONTACTOR	1	[To Translate : EN =]
U72B	P24721	MAGNETIC CONTACTOR	1	[To Translate : EN =]
U74A	P23797	RESISTOR	1	[To Translate : EN =]
U74B	P23796	RESISTOR	1	380/415 V, 50Hz, 3~
U77A	P25246	SOLENOID VALVE	1	
U77B	E01230	COIL FOR SOLENOID VALVE	4	
U77C	P24511	SOLENOID VALVE	3	
U78A	E01425	OIL HEATER	1	
U78B	E01426	OIL HEATER	1	
U79	P26468	FOUR WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U81	P26678	COIL FOR 4-WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U82A	P24381	REACTOR	1	[To Translate : EN =]
U82B	P26291	TRANSFORMER	1	[To Translate : EN =]
U85A	P26221	FAN CONTROLLER	1	FANM 20A
U85B	E01823	PCB	1	ISPM
U85C	E01427	PCB 1	1	PCB1
U89	E01498	ACCUMULATOR	1	
U98A	P26041	CABINET PANEL	1	[To Translate : EN =]
U98B	P26042	FRONT COVER	1	INSULATION ASSY
U98C	E01226	CABINET PANEL	1	[To Translate : EN =]
U98D	E01495	D-COVER UNIT	1	Assembly

CABINET AND FAN

Model: RAS-8FXNE
RAS-10FXNE
RAS-12FXNE



HITACHI

PAGE 6/7

EPN-200519F-3B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

S2ET FREE RAS-10FXNE


U01A	P25043	High Pressure Switch	2	HIGH PRESSURE
U01B	P26013	P-SENSOR	1	PD
U01C	P26014	P-SENSOR	1	PS
U04A	E00810	FUSE	4	20A
U04B	E01223	FUSE	1	12. 5A
U14A	P23970	CAPACITOR	2	2700µ F
U14B	E01627	CAPACITOR	1	1800µ F
U15A	P23508	THERMISTOR	1	TD1
U15B	P22522	THERMISTOR	1	TD2
U15C	E01420	THERMISTOR	1	TE1
U15D	P22520	THERMISTOR - aire	1	TA
U15E	E01421	THERMISTOR TE2	1	TE2
U21A	P26007	EXPANSION VALVE	1	
U21B	P26009	COIL FOR EXP. VALVE	1	
U21C	P26008	EXP. VALVE	2	
U21D	E01429	COIL FOR EXPANSION VALVE	1	
U21E	E01369	COIL FOR EXPANSION VALVE	1	
U27A	P26001	STOP VALVE	1	
U27B	P26002	STOP VALVE (référence du joint seul : P26149)	1	
U27C	P26249	STOP VALVE	1	LIQUID 3/8"
U27C	E01525	STOP VALVE	1	LIQUID 3/8"
U28A	P25044	CHECK JOINT	3	
U28B	P26292	CHECK JOINT	2	
U30A	P24399	STRAINER	2	
U30B	P16943	STRAINER	2	
U30C	P21169	DIST. STRAINER	2	
U30D	P25036	FILTRE DETENDEUR	1	
U30E	P24401	STRAINER	4	
U30F	P25037	STRAINER	1	
U32A	P17308	VIBRATION ABSORBER	8	
U32B	P13109	VIBRATION ABSORBER	6	
U34A	P24215	AIR GRILLE	1	OUTLET
U34B	P26054	AIR GRILLE	1	INLET
U34B	E01636	PROTECTOR NET	1	INLET
U40A	E01423	CONDENSER ASSY	1	
U40B	P26502	PLATE HEAT EXCHANGER	1	
U42A	P25439	CHECK VALVE	1	
U42B	P26503	CHECK VALVE	1	
U42C	P27310	CHECK VALVE	3	
U51	P26090	PROPELLER FAN	1	
U55	E01496	OIL SEPARATOR	1	
U58	E01497	L TANK	1	
U62A	P24778	NOISE FILTER	1	Before serial n° 4HE11605
U62A	P26740	NOISE FILTER	1	After serial n° 4HE11605
U62B	P23798	NOISE FILTER	1	
U65A	P19112	SPACER	16	
U65B	E00738	PUSH SPACER	2	
U70A	06931128	COMPRESSOR E405AHD-36D2Y	1	FOR INVERTER (E405AHD-36D2Y)
U70B	06953520	COMPRESSOR E605DH-59D2Y	1	(E605DH- 59D2Y)
U71	P26031	MOTOR	1	0. 81KW

S2ET FREE RAS-10FXNE

U72A	P24774	MAGNETIC CONTACTOR	1	
U72B	P24721	MAGNETIC CONTACTOR	1	
U74A	P23797	RESISTOR	1	
U74B	P23796	RESISTOR	1	380/415 V, 50Hz, 3~
U77A	P25246	SOLENOID VALVE	1	
U77B	E01230	COIL FOR SOLENOID VALVE	4	
U77C	P24511	SOLENOID VALVE	3	
U78A	E01425	OIL HEATER	1	
U78B	E01426	OIL HEATER	1	
U79	P26468	FOUR WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U81	P26678	COIL FOR 4-WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U82A	P24381	REACTOR	1	
U82B	P26291	TRANSFORMER	1	
U85A	P26221	FAN CONTROLLER	1	FANM 20A
U85B	E01823	PCB	1	ISPM
U85C	E01427	PCB 1	1	PCB1
U89	E01498	ACCUMULATOR	1	
U98A	P26041	CABINET PANEL	1	
U98B	P26042	FRONT COVER	1	INSULATION ASSY
U98C	E01226	CABINET PANEL	1	
U98D	E01495	D-COVER UNIT	1	Assembly
U99	P26088	MOTOR CLAMP	1	

ELECTRICAL EQUIPAMENT

Model: RAS-8FXNE
RAS-10FXNE
RAS-12FXNE



HITACHI

PAGE 7/7

EPN-200519F-4B

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

S2ET FREE RAS-10FXNE

U01A	P25043	High Pressure Switch	2	HIGH PRESSURE
U01B	P26013	P-SENSOR	1	PD
U01C	P26014	P-SENSOR	1	PS
U04A	E00810	FUSE	4	20A
U04B	E01223	FUSE	1	12. 5A
U14A	P23970	CAPACITOR	2	2700µ F
U14B	E01627	CAPACITOR	1	1800µ F
U15A	P23508	THERMISTOR	1	TD1
U15B	P22522	THERMISTOR	1	TD2
U15C	E01420	THERMISTOR	1	TE1
U15D	P22520	THERMISTOR - aire	1	TA
U15E	E01421	THERMISTOR TE2	1	TE2
U21A	P26007	EXPANSION VALVE	1	[To Translate : EN =]
U21B	P26009	COIL FOR EXP. VALVE	1	[To Translate : EN =]
U21C	P26008	EXP. VALVE	2	[To Translate : EN =]
U21D	E01429	COIL FOR EXPANSION VALVE	1	[To Translate : EN =]
U21E	E01369	COIL FOR EXPANSION VALVE	1	[To Translate : EN =]
U27A	P26001	STOP VALVE	1	[To Translate : EN =]
U27B	P26002	STOP VALVE (référence du joint seul : P26149)	1	[To Translate : EN =]
U27C	P26249	STOP VALVE	1	LIQUID 3/8"
U27C	E01525	STOP VALVE	1	LIQUID 3/8"
U28A	P25044	CHECK JOINT	3	[To Translate : EN =]
U28B	P26292	CHECK JOINT	2	[To Translate : EN =]
U30A	P24399	STRAINER	2	[To Translate : EN =]
U30B	P16943	STRAINER	2	[To Translate : EN =]
U30C	P21169	DIST. STRAINER	2	[To Translate : EN =]
U30D	P25036	FILTRE DETENDEUR	1	[To Translate : EN =]
U30E	P24401	STRAINER	4	[To Translate : EN =]
U30F	P25037	STRAINER	1	[To Translate : EN =]
U32A	P17308	VIBRATION ABSORBER	8	[To Translate : EN =]
U32B	P13109	VIBRATION ABSORBER	6	[To Translate : EN =]
U34A	P24215	AIR GRILLE	1	OUTLET
U34B	P26054	AIR GRILLE	1	INLET
U34B	E01636	PROTECTOR NET	1	INLET
U40A	E01423	CONDENSER ASSY	1	[To Translate : EN =]
U40B	P26502	PLATE HEAT EXCHANGER	1	[To Translate : EN =]
U42A	P25439	CHECK VALVE	1	[To Translate : EN =]
U42B	P26503	CHECK VALVE	1	[To Translate : EN =]
U42C	P27310	CHECK VALVE	3	[To Translate : EN =]
U51	P26090	PROPELLER FAN	1	[To Translate : EN =]
U55	E01496	OIL SEPARATOR	1	[To Translate : EN =]
U58	E01497	L TANK	1	[To Translate : EN =]
U62A	P24778	NOISE FILTER	1	Before serial n° 4HE11605
U62A	P26740	NOISE FILTER	1	After serial n° 4HE11605
U62B	P23798	NOISE FILTER	1	
U65A	P19112	SPACER	16	
U65B	E00738	PUSH SPACER	2	
U70A	06931128	COMPRESSOR E405AHD-36D2Y	1	FOR INVERTER (E405AHD-36D2Y)
U70B	06953520	COMPRESSOR E605DH-59D2Y	1	(E605DH- 59D2Y)
U71	P26031	MOTOR	1	0. 81KW

S2ET FREE RAS-10FXNE

U72A	P24774	MAGNETIC CONTACTOR	1	
U72B	P24721	MAGNETIC CONTACTOR	1	
U74A	P23797	RESISTOR	1	
U74B	P23796	RESISTOR	1	380/415 V, 50Hz, 3~
U77A	P25246	SOLENOID VALVE	1	[To Translate : EN =]
U77B	E01230	COIL FOR SOLENOID VALVE	4	[To Translate : EN =]
U77C	P24511	SOLENOID VALVE	3	[To Translate : EN =]
U78A	E01425	OIL HEATER	1	[To Translate : EN =]
U78B	E01426	OIL HEATER	1	[To Translate : EN =]
U79	P26468	FOUR WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U81	P26678	COIL FOR 4-WAY VALVE	2	Before serial n° 4FE03575 send Four Way Valve P26468 + Coil P26678
U82A	P24381	REACTOR	1	
U82B	P26291	TRANSFORMER	1	
U85A	P26221	FAN CONTROLLER	1	FANM 20A
U85B	E01823	PCB	1	ISPM
U85C	E01427	PCB 1	1	PCB1
U89	E01498	ACCUMULATOR	1	[To Translate : EN =]
U98A	P26041	CABINET PANEL	1	[To Translate : EN =]
U98B	P26042	FRONT COVER	1	INSULATION ASSY
U98C	E01226	CABINET PANEL	1	[To Translate : EN =]
U98D	E01495	D-COVER UNIT	1	Assembly
U99A	P22528	SENSOR	1	CT Sensor for fixed-speed compressor