





Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWM-6.0N1E

1	E06155	ELECTRIC HEATER	1		
1-1	E06159	SURFACE THERMOSTAT	1		Part of Electric Heater
2	E06307	Air Purge	1		
3	E02475	SECURITY VALVE	1		
4	E04873	GASKET	1		for Union 5 to Security Valve connection.
5	E02507	UNION	1		
6	E02546	DRAIN PIPE	1		
7	E07224	PRESSURE SENSOR	1		
8	E07195	PHEx UNIT	1		Assembly.
8-1	E06536	PALTE HEX	1		
8-2	E07221	EXPANSION VALVE ASSY	1		Exp.Valve + Pipes + Strainers + Silencer
8-3	E03078	EXPANSION VALVE	1		
8-4	E02487	UNION	1		Liquid connection.
8-5	E02488	UNION	1		Gas connection
8-6	R4225	Flare Nut	1		Liquid connection.
8-7	R4227	Flare Nut	1		Gas connection
9	E02496	GASKET	2		for Electric Heater connections.
10	E03832	Gasket	2		for Pump connections.
11	E02528	GASKET	2		for Filter Ball connections.
12	E07103	WATER PUMP	1		
13	E04840	FILTER BALL	1		
13-1	E04841	FILTER	1		
13-2	E04842	SEEGER	1		
14	E05014	MANOMETER	1		
15	E07145	THERMISTOR ASSY	1		Water In THM.
16	E04986	THERMISTOR ASSY 1	1		Water Out THM.
17	E04989	THERMISTOR ASSY 1	1		Water Out PHEx THM.
18	E04991	THERMISTOR ASSY 2	1		Gas THM.
19	E04994	THERMISTOR ASSY 2	1		Liquid THM.
20	E03180	EXPANSION VALVE COIL	1		
21	E07191	P-SPRING	1		
22	E02550	P-SPRING	1		
23	E02551	P-SPRING	2		
24	E02497	GASKET	1		Vessel connection.
25	E04893	EXPANSION VESSEL (6L)	1		
26	E07198	E-BOX COVER ASSY	1		Plate + Labels.
27	E07225	GEN 2.5 WRC ASM ASSY	1		
28	E02504	CLAMP	2		
29	E07199	LCD SUPPORT	1		
30	E07200	SERVICE COVER ASSY	1		Assembly.
30-1	E07132	LCD FRAME	1		
30-2	E07226	HITACHI LABEL	1		
31	E02552	WALL SUPPORT	1		
32	E04824	GASKET	4		for Shutdown Valves connections.
33	E04846	SHUTDOWN VALVE	2		
34	E05026	CLAMP	1		
35	E01193	P-SPRING	1		
36	P25678	SUS SCREW	1		



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWM-6.0N1E

1	E07070	INSTRUCTION ASSY PCB	1	
2	E01789	SPACER	12	
3	E02519	TERMINAL BOARD	1	
4	E04778	TERMINAL BOARD	1	
5	E04779	RELAY	3	
7	E04781	FUSE	3	12,5A
8	E04782	FUSE	1	20A
9	E02516	FUSE HOLDER	4	
10	E07134	ROCKER SWITCH	1	
11	E02012	CLAMP	1	
12	E02060	RUBBER BUSH	9	
13	E04785	THERMOSTAT	1	
14	E07205	ELECTRICAL WIRING DIAGRAM	1	Assembly (Plate + Components + Harness)
15	E07207	E-BOX SUB ASSY	1	Only plate (without components)