




Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWD-3.0NWE-200S


1	E04869	FOOT	4	
2	E04966	WATER TANK 200L	1	
2-1	E04088	TANK HEATER	1	
2-2	E04768	BOTTOM TANK FLANGE	1	
3	E04084	FRONT INSULATION	1	
4	E04085	BACK INSULATION	1	
5	E04068	TH INSULATION	1	
6	E04893	EXPANSION VESSEL (6L)	1	
7	E04048	FLEXIBLE PIPE	1	
8	E05009	PHEX UNIT	1	
8-1	E04896	PLATE HEX	1	
8-2	E03077	EXPANSION VALVE	1	
8-3	P25041	STRAINER	2	
9	E04868	SEAL NUT	2	
10	E04871	SEAL GASKET	2	
11	E04073	UNION	1	
12	E02488	UNION	1	
13	E02490	FLARE NUT	1	
14	E02487	UNION	1	
15	E02489	FLARE NUT	1	
16	E04894	CIRCULATEUR	1	
17	E05023	E-Heater Unit	1	
18	E03832	Gasket	8	
19	E04897	FILTER BALL	1	
19-1	E04898	FILTER	1	
19-2	E04899	SEEGER	1	
20	E02528	GASKET	7	
21	E03271	3 WAY VALVE	1	
22	E04052	GASKET	2	
23	E02475	SECURITY VALVE	1	
24	E04873	GASKET	1	
25	E02507	UNION	1	
26	E02546	DRAIN PIPE	1	
27	E04040	AIR PURGE	1	
28	E02494	PRESSURE SW	1	
29	E05017	GASKET	1	
30	E05006	LCD SUPPORT	1	
31	E04960	REMOTE CONTROL AS	1	
32	E05014	MANOMETER	1	
33	E05021	E-BOX COVER ASSY	1	
34	E02549	P-SPRING	1	
35	E02550	P-SPRING	1	
36	E01193	P-SPRING	3	
37	E01897	HANDLE	2	
38	E04069	MINI VALVE	2	
39	E02497	GASKET	3	
40	E05013	UPPER COVER	1	
41	E05012	SERVICE COVER ASSY	1	
42	E04955	XEK12635 A - LCD FRAME	1	
43	E04944	XEK39388 A - YUTAKI FRAME	1	

MODULE HYDRAULIQUE

RWD-3.0NWE-200S

44	E04954	GASKET	2
45	E05019	SHUTDOWN VALVE	2
46	E04928	THERMISTOR ASSY 1	1
47	E04980	THERMISTOR ASSY 1	1
48	E04981	THERMISTOR ASSY 1	1
49	E04982	THERMISTOR ASSY 2	1
50	E04983	THERMISTOR ASSY 2	1
51	E04965	EXP. VALVE COIL	1
52	E05020	THERMISTOR DHWT	1
53	E04945	XEK12635 A - LCD FRAME	2
54	E05026	CLAMP	1
55	E05027	MANUAL AIR PURGE	1
56	E02501	Screw	4
57	E02060	RUBBER BUSH	3
60	E05058	SIDE COVER L	1
61	E05059	SIDE COVER R	1
62	E06660	ANODE	1

LOCATION OF SPARE PARTS IN THE UNIT
ELECTRICAL EQUIPMENT



RWD-3.0NWE-200S-42
RWD-3.0NWE-200S-41
RWD-3.0NWE-200S-40
RWD-3.0NWE-200S-39
RWD-3.0NWE-200S-38
RWD-3.0NWE-200S-37
RWD-3.0NWE-200S-36
RWD-3.0NWE-200S-35
RWD-3.0NWE-200S-34
RWD-3.0NWE-200S-33
RWD-3.0NWE-200S-32
RWD-3.0NWE-200S-31
RWD-3.0NWE-200S-30
RWD-3.0NWE-200S-29
RWD-3.0NWE-200S-28
RWD-3.0NWE-200S-27
RWD-3.0NWE-200S-26
RWD-3.0NWE-200S-25
RWD-3.0NWE-200S-24
RWD-3.0NWE-200S-23
RWD-3.0NWE-200S-22
RWD-3.0NWE-200S-21
RWD-3.0NWE-200S-20
RWD-3.0NWE-200S-19
RWD-3.0NWE-200S-18
RWD-3.0NWE-200S-17
RWD-3.0NWE-200S-16
RWD-3.0NWE-200S-15
RWD-3.0NWE-200S-14
RWD-3.0NWE-200S-13
RWD-3.0NWE-200S-12
RWD-3.0NWE-200S-11
RWD-3.0NWE-200S-10
RWD-3.0NWE-200S-09
RWD-3.0NWE-200S-08
RWD-3.0NWE-200S-07
RWD-3.0NWE-200S-06
RWD-3.0NWE-200S-05
RWD-3.0NWE-200S-04
RWD-3.0NWE-200S-03
RWD-3.0NWE-200S-02
RWD-3.0NWE-200S-01

EPN-201605A

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWD-3.0NWE-200S

1	E04665	INSTRUCTION ASSY PCB	1	
2	E01789	SPACER	12	
3	E02519	TERMINAL BOARD	1	
4	E04778	TERMINAL BOARD	1	
5	E04779	RELAY	3	
6	E04780	FUSE	3	
8	E04782	FUSE	1	
9	E02516	FUSE HOLDER	4	
10	E03828	Rocker Swith	1	
11	E02012	CLAMP	1	
12	E02060	RUBBER BUSH	9	
13	E04785	THERMOSTAT	1	
14	E04786	ELECTRICAL BOX	1	
16	E04791	E-BOX SUBASSY	1	