


CASSETTE

RCD-2FS


Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT A
MODELS: RCD-1FS, RCD-1.5FS, RCD-2FS, RCD-2.5FS



LOCATION OF ELECTRICAL EQUIPMENT
IN THE ELECTRICAL BOX



DRPA1-C01

- 25 -

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

CASSETTE

RCD-2FS

U02	60299751	REMOTE CONTROL PC-2H2	1	ASSEMBLY REMOTE CONTROL SW
U04A	P12416	FUSE	2	3A FOR CONTROL CIRCUIT
U04B	P17147	FUSE	1	0. 5A FOR DEW PROTECT HEATER
U14	P14139	CAPACITOR	1	2MF 440VAC
U15A	P19208	THERMISTOR	1	THM3 AIR INLET
U15B	P18963	THERMISTOR	1	THM4 AIR OUTLET
U15C	P18955	THERMISTOR	1	THM5 FREEZE PROTECTION
U15D	P19649	P19649	1	THM7 GAS
U21	P17237	EXP. VALVE	1	
U31	P18971	AIR FILTER	1	FOR P- 23DL3A
U34	P20075	AIR GRILLE	1	FOR P- 23DL3A
U36	P16834	RUNNER	3	
U37	P17290	FAN CASING	3	
U41	P20002	HEAT EXCHANGER	1	
U65	P19112	SPACER	8	
U71A	P17685	MOTOR	1	FAN MOTOR
U71B	P17396	DISCHARGE MECHANISM	1	FOR DISCHARGE MECHANISM
U71C	P19989	INVALID COUNTRY OF ORIGIN	1	FOR P- 23DL3A SWING MOTOR
U75	P15964	AUX. RELAY	1	
U82	P19991	TRANSFORMER	1	
U85A	P18515	PRINTED CIRCUIT BOARD	1	POWER SUPPLY BOARD: PCB (P)
U85B	P18949	PRINTED CIRCUIT BOARD	1	CONTROLLING BOARD: PCB (M)
U87	P19108	FLOAT SW	1	