


MONOSPLIT

RASM-5RW1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-5RW1E


2	XEK13468A	Compressor	1	
3	E06435	TERMINAL COVER - 4CY00988	1	
4	E06436	GASKET - 4CYC01047	1	
5	E06437	NUT - 3CY00004	1	
6	E06438	RUBBER WASHER - 4CYC00174	1	
7	E06439	SLEEVE - 4CYC01042	1	
8	E06877	THERMAL CUT-OUT	1	
9	E06433	RUBBER GROMMET	3	
10	P21245	SPECIAL NUT	2	
11	E06434	TERMINAL COVER - 4CY00997	3	
12	1000011422	CONDENSER ASSY	1	Assembly
12-1	E03458	Header G Unit	1	Assembly
12-2	1000011455	Header L Assy	1	Assembly
12-2-1	1000011457	EVO Assy	1	Assembly
12-2-1-2	P25037	STRAINER	2	
12-3	E02107	END PLATE ASSY	1	
13	E02105	ATTACHING PLATE	1	
14	E06845	ACCUMULATOR	1	
15	1000011472	Pipe S Assy	1	Assembly
15-1	P24399	STRAINER	1	
15-2	E06312	P-SENSOR (S)	1	Ps
16	1000011433	4-Way Valve Assy	1	Assembly
18	1000011459	Partition Assy	1	
19	E03363	V-Stay	1	
20	XEK52845A	VALVE STAY	1	
21	E06335	CLAMP L ASSY	1	Assembly
22	E06110	Fan Motor	2	
23	E06482	PROPELLER FAN	2	
24	E06379	SHROUD S ASSY	1	Assembly
24-1	E06317	SHROUD S	1	
24-2	E02876	AIR GRILLE	2	Air Outlet
24-3	E01897	HANDLE	1	
25	E05855	SIDE COVER LB	1	
26	E05954	EXPV COIL	1	Coil for Expansion Valve (EVO)
30	E06403	C-HEATER	1	
53	1000011467	Rear Cover L Assy	1	Assembly
53-1	P23833	H COVER	1	
53-2	E01897	HANDLE	1	
54	E02148	U-COVER ASSY	1	Assembly
55	1000011466	S Cover B Assy	1	
56	1000011447	Service Cover L Assy	1	Assembly
57	E01897	HANDLE	1	
58	E04824	GASKET	4	
59	XEK26629B	Acoustical Cover	1	
60	E06370	ACOUSTICAL COVER 2 (UP)	1	
17	1000011465	Economizer Unit	1	Assembly
33	E06600	Thermistor Assy	1	Te
35	E06598	Thermistor Assy	1	Ta
36	E01901	TH PLATE	1	
37	XEK26452R	THERMISTOR ASSY	1	Ts

MONOSPLIT

RASM-5RW1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-5RW1E


16-1	E05578	Reversing Valve	1	RVR
16-2	1000011458	D Pipe Assy	1	Assembly
16-2-1	P28629	Silencer	1	
16-2-2	P29897	Check Valve	1	
16-2-3	E04508	P-Sensor	1	Pd
16-2-4	E03359	PRESSURE SW	1	PSH (High)
16-3	1000011473	SVA Assy	1	Assembly
16-3-1	E06838	CAPILLARY	1	
16-3-2	P25246	SOLENOID VALVE	1	SVA
16-4	1000011474	SVA Assy	1	Assembly
16-4-1	17H07462C	Capillary	1	
16-4-2	P25246	SOLENOID VALVE	1	SVC
16-5	E01160	CHECK JOINT	1	
16-6	E01512	Stop Valve	1	5/8
17	1000011465	Economizer Unit	1	Assembly
17-1	XEK27444A	ECONOMIZER	1	
17-2	P25246	SOLENOID VALVE	1	SVE
17-3	P25036	FILTRE DETENDEUR	1	
17-5	E03078	EXPANSION VALVE	1	EVI
17-6	E06485	Stop Valve	1	3/8
27	1000011716	Coil Harness	1	RVR
28	1000011717	Coil Harness	1	SVA
29	1000011468	Coil Harness	1	SVC
31	E06597	Thermistor Assy	1	Td
32	17G27651A	P-Spring	1	
33	E06600	Thermistor Assy	1	Te
34	E05646	TH-PLATE	1	
35	E06598	Thermistor Assy	1	Ta
36	E01901	TH PLATE	1	
37	XEK26452R	THERMISTOR ASSY	1	Ts
38	E02444	P-SPRING	1	
39	XEK26452Q	THERMISTOR ASSY	1	Teco
40	17G27651D	P-Spring	1	
41	E03180	EXPANSION VALVE COIL	1	Coil for Expansion Valve (EVI)
42	E03291	EXPV COIL	1	Coil for Expansion Valve (EVE)
43	1000011469	COIL HARNESS	1	SVE

MONOSPLIT

RASM-5RW1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-5RW1E


44	1000011463	PHEX Unit	1	Assembly
44-1	E06536	PALTE HEX	1	
44-2	XEK53017B	WH Heater	1	
45	E04040	AIR PURGE	1	
46	E07143	THERMISTOR ASSY 1	1	Water In Thermistor
47	E04929	THERMISTOR ASSY 1	1	Water Out Thermistor
48	E02551	P-SPRING	2	
49	E04991	THERMISTOR ASSY 2	1	Gas Thermistor
50	E02550	P-SPRING	1	
51	E04931	THERMISTOR ASSY 2	1	Liquid Thermistor
52	E02549	P-SPRING	1	

MONOSPLIT

RASM-5RW1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-5RW1E


1	1000011426	Electrical Box	1	Assembly
2	1000011435	E-Box PCB Unit	1	Assembly
2-1	E06392	E-BOX PCB PLATE	1	Assembly
2-2	E00705	TERMINAL BOARD	1	
2-3	E06349	NOISE FILTER	1	
2-4	P20985	PLASTIC MATERIAL	6	
2-5	1000011413	PCB	1	
2-6	E04603	SPACER	6	
2-7	E00738	PUSH SPACER	1	
3	E06406	E-BOX UPPER SUPPORT	1	
4	E06352	E-BOX PO121 AUX UNIT	1	Assembly
4-1	E06393	E-BOX PO121 AUX PLATE	1	
4-2	P29696	PCB	1	
4-3	P31332	REACTOR UNIT	1	
4-4	E04603	SPACER	6	
5	1000011436	E-Box INV Unit	1	Assembly
5-1	XEK26620B	DRV180 Assy	1	
5-2	E06391	PLATE INV ASSY	1	

MONOSPLIT

RASM-5RW1E

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MONOSPLIT

RASM-5RW1E

1	1000011428	Electrical Box	1	Assembly
2	E07042	E-BOX	1	
3	1000011412	PCB	1	
4	E01789	SPACER	12	
5	E04783	HARNESS LIFTER	3	
6	E04784	ENDLING SADDLE	2	