


MODULE HYDRAULIQUE

RWM-3FSN2E1

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWM-3FSN2E1

1	E01600	General ON/OFF SW	1	(SW9)
2	E01602	ON/OFF Elect. Heater SW	1	(SW10)
4	E01602	ON/OFF Elect. Heater SW	1	(SW13)
5	E01602	ON/OFF Elect. Heater SW	1	(SW12)
6	E01479	FUSE	1	Power Line (2A)(EF1)
9	E01452	ELEC. HEATER RELAY	1	(AR1)
10	E01518	ELEC HEATER AUX. RELAY	1	(AR2)
12	E01295	TRANSFORMER	1	(TE)
13	E01687	PCB	1	(PCB1)
14	E02222	CONTROL PCB	1	(PCB2)
15	E02223	SAMLL SETTING PCB	1	(PCB3)
16	E02224	AUXILIARY PCB	1	(PCB4)
17	E01693	PC-ART	1	PC- ART (RCS)
18	E02225	PCB2 - PCB3	1	
19	E01629	PCB Main Wire	1	
20	E02231	PCB2 - PCB4 WIRE	1	
21	E01464	MANOMETRE	1	
22	E01674	Adapter 1/2M - 1/4F	1	
24	E01466	RESISTANCE	1	
25	E00934	THERMISTOR	1	For liquid Pipe
26	E00938	THERMISTOR	1	For Gas Pipe
27	E02227	OUTDOOR SENSOR THM	1	
28	E02228	WATER SENSOR THM	3	Water Thermistors
29	E01640	TIMER	1	
30	E02229	TERMINAL BOARD 1	1	
32	E01657	WATER PUMP BODY	1	
33	E01632	Joint 95x115x2	1	
34	E01658	Joint 76x85x3	1	
35	E01455	WATER PUMP	1	Pump+ Joint+ Screws(x4)
37	E01654	Pump Outlet Pipe	1	
38	E01659	Joint 26x34	1	
39	E01462	WATER PRESSURE	1	
40	E01674	Adapter 1/2M - 1/4F	2	
41	E01463	WATER FLOW SW	1	
42	E01465	AIR PURGE	1	
45	E01664	Xbrass 1/2 FFFF	1	
46	E01458	EXPANSION VESSEL	1	
47	E01660	Joint 20x27	1	
48	E00679	EXP. VALVE CORD	1	
49	E01446	EXP. VALVE ASSY	1	
51	E01467	SECURITY VALVE	1	
52	E01665	Tap	1	
53	E01663	Tbrass 1/2 FFF	1	
54	E01468	WATER SOURCE PORT	1	
55	E01630	CHECK VALVE	1	
56	E01633	HOSE	1	
61	E01669	DRAIN PUMP	1	
62	E01949	CASING	1	
63	E01950	SET OF SCREWS	1	
64	E01835	Exchanger Assy	1	

MODULE HYDRAULIQUE

RWM-3FSN2E1


65	E01670	Exchanger	1	
66	E01671	Joint 45x54x3	1	
67	E01672	Brass Connector	1	
68	E01645	Water Intlet Joint	1	For Water intlet Joint
69	E01646	Liquid&Gas Joint	2	For Liquid /Gas Joint
70	E01647	Heat Exchanger Joint	1	For Heat exchanger cover Joint
71	E01660	Joint 20x27	1	
72	E01678	Adapter 3/4F - 1/2M	1	
73	E01673	Brass connector 1F	1	
76	E01838	Jacket insulation	1	
77	E01659	Joint 26x34	4	
78	E01836	THERMO CASE	1	
79	E01837	THERMO CASE COVER	1	
82	E01947	PRESSOSTAT WIRE	1	
83	E02232	Adapter 1F-1/2F	1	

MODULE HYDRAULIQUE

RWM-3FSN2E1

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWM-3FSN2E1

1	E01600	General ON/OFF SW	1	(SW9)
2	E01602	ON/OFF Elect. Heater SW	1	(SW10)
4	E01602	ON/OFF Elect. Heater SW	1	(SW13)
5	E01602	ON/OFF Elect. Heater SW	1	(SW12)
6	E01479	FUSE	1	Power Line (2A)(EF1)
9	E01452	ELEC. HEATER RELAY	1	(AR1)
10	E01518	ELEC HEATER AUX. RELAY	1	(AR2)
12	E01295	TRANSFORMER	1	(TE)
13	E01687	PCB	1	(PCB1)
14	E02222	CONTROL PCB	1	(PCB2)
15	E02223	SAMLL SETTING PCB	1	(PCB3)
16	E02224	AUXILIARY PCB	1	(PCB4)
17	E01693	PC-ART	1	PC- ART (RCS)
18	E02225	PCB2 - PCB3	1	
19	E01629	PCB Main Wire	1	
20	E02231	PCB2 - PCB4 WIRE	1	
21	E01464	MANOMETRE	1	
22	E01674	Adapter 1/2M - 1/4F	1	
24	E01466	RESISTANCE	1	
25	E00934	THERMISTOR	1	For liquid Pipe
26	E00938	THERMISTOR	1	For Gas Pipe
27	E02227	OUTDOOR SENSOR THM	1	
28	E02228	WATER SENSOR THM	3	Water Thermistors
29	E01640	TIMER	1	
30	E02229	TERMINAL BOARD 1	1	
32	E01657	WATER PUMP BODY	1	
33	E01632	Joint 95x115x2	1	
34	E01658	Joint 76x85x3	1	
35	E01455	WATER PUMP	1	Pump+ Joint+ Screws(x4)
37	E01654	Pump Outlet Pipe	1	
38	E01659	Joint 26x34	1	
39	E01462	WATER PRESSURE	1	
40	E01674	Adapter 1/2M - 1/4F	2	
41	E01463	WATER FLOW SW	1	
42	E01465	AIR PURGE	1	
45	E01664	Xbrass 1/2 FFFF	1	
46	E01458	EXPANSION VESSEL	1	
47	E01660	Joint 20x27	1	
48	E00679	EXP. VALVE CORD	1	
49	E01446	EXP. VALVE ASSY	1	
51	E01467	SECURITY VALVE	1	
52	E01665	Tap	1	
53	E01663	Tbrass 1/2 FFF	1	
54	E01468	WATER SOURCE PORT	1	
55	E01630	CHECK VALVE	1	
56	E01633	HOSE	1	
61	E01669	DRAIN PUMP	1	
62	E01949	CASING	1	
63	E01950	SET OF SCREWS	1	
64	E01835	Exchanger Assy	1	

MODULE HYDRAULIQUE

RWM-3FSN2E1


65	E01670	Exchanger	1	
66	E01671	Joint 45x54x3	1	
67	E01672	Brass Connector	1	
68	E01645	Water Intlet Joint	1	For Water intlet Joint
69	E01646	Liquid&Gas Joint	2	For Liquid /Gas Joint
70	E01647	Heat Exchanger Joint	1	For Heat exchanger cover Joint
71	E01660	Joint 20x27	1	
72	E01678	Adapter 3/4F - 1/2M	1	
73	E01673	Brass connector 1F	1	
76	E01838	Jacket insulation	1	
77	E01659	Joint 26x34	4	
78	E01836	THERMO CASE	1	
79	E01837	THERMO CASE COVER	1	
82	E01947	PRESSOSTAT WIRE	1	
83	E02232	Adapter 1F-1/2F	1	

MODULE HYDRAULIQUE

RWM-3FSN2E1

Pièces détachées

Main view



Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWM-3FSN2E1

1	E01600	General ON/OFF SW	1	(SW9)
2	E01602	ON/OFF Elect. Heater SW	1	(SW10)
4	E01602	ON/OFF Elect. Heater SW	1	(SW13)
5	E01602	ON/OFF Elect. Heater SW	1	(SW12)
6	E01479	FUSE	1	Power Line (2A)(EF1)
9	E01452	ELEC. HEATER RELAY	1	(AR1)
10	E01518	ELEC HEATER AUX. RELAY	1	(AR2)
12	E01295	TRANSFORMER	1	(TE)
13	E01687	PCB	1	(PCB1)
14	E02222	CONTROL PCB	1	(PCB2)
15	E02223	SAMLL SETTING PCB	1	(PCB3)
16	E02224	AUXILIARY PCB	1	(PCB4)
17	E01693	PC-ART	1	PC- ART (RCS)
18	E02225	PCB2 - PCB3	1	
19	E01629	PCB Main Wire	1	
20	E02231	PCB2 - PCB4 WIRE	1	
21	E01464	MANOMETRE	1	
22	E01674	Adapter 1/2M - 1/4F	1	
24	E01466	RESISTANCE	1	
25	E00934	THERMISTOR	1	For liquid Pipe
26	E00938	THERMISTOR	1	For Gas Pipe
27	E02227	OUTDOOR SENSOR THM	1	
28	E02228	WATER SENSOR THM	3	Water Thermistors
29	E01640	TIMER	1	
30	E02229	TERMINAL BOARD 1	1	
32	E01657	WATER PUMP BODY	1	
33	E01632	Joint 95x115x2	1	
34	E01658	Joint 76x85x3	1	
35	E01455	WATER PUMP	1	Pump+ Joint+ Screws(x4)
37	E01654	Pump Outlet Pipe	1	
38	E01659	Joint 26x34	1	
39	E01462	WATER PRESSURE	1	
40	E01674	Adapter 1/2M - 1/4F	2	
41	E01463	WATER FLOW SW	1	
42	E01465	AIR PURGE	1	
45	E01664	Xbrass 1/2 FFFF	1	
46	E01458	EXPANSION VESSEL	1	
47	E01660	Joint 20x27	1	
48	E00679	EXP. VALVE CORD	1	
49	E01446	EXP. VALVE ASSY	1	
51	E01467	SECURITY VALVE	1	
52	E01665	Tap	1	
53	E01663	Tbrass 1/2 FFF	1	
54	E01468	WATER SOURCE PORT	1	
55	E01630	CHECK VALVE	1	
56	E01633	HOSE	1	
61	E01669	DRAIN PUMP	1	
62	E01949	CASING	1	
63	E01950	SET OF SCREWS	1	
64	E01835	Exchanger Assy	1	

MODULE HYDRAULIQUE

RWM-3FSN2E1

65	E01670	Exchanger	1	
66	E01671	Joint 45x54x3	1	
67	E01672	Brass Connector	1	
68	E01645	Water Intlet Joint	1	For Water intlet Joint
69	E01646	Liquid&Gas Joint	2	For Liquid /Gas Joint
70	E01647	Heat Exchanger Joint	1	For Heat exchanger cover Joint
71	E01660	Joint 20x27	1	
72	E01678	Adapter 3/4F - 1/2M	1	
73	E01673	Brass connector 1F	1	
76	E01838	Jacket insulation	1	
77	E01659	Joint 26x34	4	
78	E01836	THERMO CASE	1	
79	E01837	THERMO CASE COVER	1	
82	E01947	PRESSOSTAT WIRE	1	
83	E02232	Adapter 1F-1/2F	1	