





| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWM-10.0N1E

|      |        |                        |   |                                                                                     |                                           |
|------|--------|------------------------|---|-------------------------------------------------------------------------------------|-------------------------------------------|
| 1    | E06157 | ELECTRIC HEATER        | 1 |  |                                           |
| 1-1  | E06159 | SURFACE THERMOSTAT     | 1 |                                                                                     | Part of Electric Heater                   |
| 2    | E06307 | Air Purge              | 1 |  |                                           |
| 3    | E02475 | SECURITY VALVE         | 1 |                                                                                     |                                           |
| 4    | E04873 | GASKET                 | 1 |                                                                                     | for Union 5 to Security Valve connection. |
| 5    | E02507 | UNION                  | 1 |                                                                                     |                                           |
| 6    | E02546 | DRAIN PIPE             | 1 |                                                                                     |                                           |
| 7    | E07224 | PRESSURE SENSOR        | 1 |                                                                                     |                                           |
| 8    | E07218 | PHEx UNIT              | 1 |                                                                                     | Assembly.                                 |
| 8-1  | E06538 | PLATE HEX              | 1 |                                                                                     |                                           |
| 8-2  | E07223 | EXPANSION VALVE ASSY   | 1 |                                                                                     | Exp.Valve + Pipes + Strainers + Silencer  |
| 8-3  | E03078 | EXPANSION VALVE        | 2 |                                                                                     |                                           |
| 8-4  | E02775 | UNION                  | 1 |                                                                                     | Liquid connection.                        |
| 8-5  | R4226  | Flare Nut              | 1 |                                                                                     | Liquid connection.                        |
| 9    | E02496 | GASKET                 | 4 |                                                                                     | for Pump and Electric Heater connections. |
| 10   | E02528 | GASKET                 | 2 |                                                                                     | for Filter Ball connections.              |
| 11   | E04977 | PUMP                   | 1 |                                                                                     |                                           |
| 12   | E04840 | FILTER BALL            | 1 |                                                                                     |                                           |
| 12-1 | E04841 | FILTER                 | 1 |                                                                                     |                                           |
| 12-2 | E04842 | SEEGER                 | 1 |                                                                                     |                                           |
| 13   | E05014 | MANOMETER              | 1 |                                                                                     |                                           |
| 14   | E07146 | THERMISTOR ASSY        | 1 |                                                                                     | Water In THM.                             |
| 15   | E04987 | THERMISTOR ASSY 1      | 1 |                                                                                     | Water Out THM.                            |
| 16   | E04990 | THERMSITOR ASSY 1      | 1 |                                                                                     | Water Out PHEx THM.                       |
| 17   | E04992 | THERMSITOR ASSY 2      | 1 |                                                                                     | Gas THM.                                  |
| 18   | E04995 | THERMSITOR ASSY 2      | 1 |                                                                                     | Liquid THM.                               |
| 19   | E03180 | EXPANSION VALVE COIL   | 2 |                                                                                     |                                           |
| 20   | E07191 | P-SPRING               | 1 |                                                                                     |                                           |
| 21   | E02444 | P-SPRING               | 1 |                                                                                     |                                           |
| 22   | E02551 | P-SPRING               | 3 |                                                                                     |                                           |
| 23   | E02497 | GASKET                 | 1 |                                                                                     | Vessel connection.                        |
| 24   | E04976 | EXPANSION VESSEL (10L) | 1 |                                                                                     |                                           |
| 25   | E07198 | E-BOX COVER ASSY       | 1 |                                                                                     | Plate + Labels.                           |
| 26   | E07225 | GEN 2.5 WRC ASM ASSY   | 1 |                                                                                     |                                           |
| 27   | E02504 | CLAMP                  | 2 |                                                                                     |                                           |
| 28   | E07199 | LCD SUPPORT            | 1 |                                                                                     |                                           |
| 29   | E07203 | SERVICE COVER ASSY     | 1 |                                                                                     | Assembly.                                 |
| 29-1 | E07132 | LCD FRAME              | 1 |                                                                                     |                                           |
| 29-2 | E07226 | HITACHI LABEL          | 1 |                                                                                     |                                           |
| 30   | E02790 | WALL SUPPORT           | 1 |                                                                                     |                                           |
| 31   | E04824 | GASKET                 | 4 |                                                                                     | for Shutdown Valves connections.          |
| 32   | E04846 | SHUTDOWN VALVE         | 2 |                                                                                     |                                           |
| 33   | E05026 | CLAMP                  | 1 |                                                                                     |                                           |
| 34   | P25678 | SUS SCREW              | 1 |                                                                                     |                                           |



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWM-10.0N1E

|    |        |                           |    |                                         |
|----|--------|---------------------------|----|-----------------------------------------|
| 1  | E07070 | INSTRUCTION ASSY PCB      | 1  |                                         |
| 2  | E01789 | SPACER                    | 12 |                                         |
| 3  | E02519 | TERMINAL BOARD            | 1  |                                         |
| 4  | E04778 | TERMINAL BOARD            | 1  |                                         |
| 5  | E04779 | RELAY                     | 3  |                                         |
| 8  | E04782 | FUSE                      | 4  | 20A                                     |
| 9  | E02516 | FUSE HOLDER               | 4  |                                         |
| 10 | E07134 | ROCKER SWITCH             | 1  |                                         |
| 11 | E02012 | CLAMP                     | 1  |                                         |
| 12 | E02060 | RUBBER BUSH               | 9  |                                         |
| 13 | E04785 | THERMOSTAT                | 1  |                                         |
| 14 | E07206 | ELECTRICAL WIRING DIAGRAM | 1  | Assembly (Plate + Components + Harness) |
| 15 | E07207 | E-BOX SUB ASSY            | 1  | Only plate (without components)         |