


LOCATION OF SPARE PARTS IN THE UNIT
ELECTRICAL EQUIPMENT

RWH-4.0NFWE
RWH-4.0NFE
RWH-5.0NFWE
RWH-5.0NFE
RWH-6.0NFWE
RWH-6.0NFE




EPN-201606A

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWH-5.0NFWE

1	P30843	INVERTER MODULE	1	
3	E04666	INSTRUCTION ASSY PCB	1	
6	P26740	NOISE FILTER	1	
7	P23970	CAPACITOR	2	
8	E02438	Radiateur pour carte	1	
9	E04778	TERMINAL BOARD	1	
10	P28599	RESISTOR	1	
11	P24721	MAGNETIC CONTACTOR	1	
12	E04779	RELAY	1	
13	P30831	RESISTOR	1	
16	E01015	FUSE HOLDER	2	
18	E02519	TERMINAL BOARD	1	
19	E03818	Reactor Assy	1	
21	E03828	Rocker Swith	1	
22	E02516	FUSE HOLDER	1	
23	E04782	FUSE	1	
24	E00810	FUSE	2	
25	E01789	SPACER	18	
26	E02012	CLAMP	4	
27	E02060	RUBBER BUSH	4	
28	E04775	RUBBER BUSHING	2	
29	E04792	FAN BOX	2	
30	P24786	Capacitor	1	
31	E04793	FAN SUPPORT SUBASSY	1	
33	E04795	E-BOX SUB ASSY	1	
35	E04797	ELECTRICA BOX	1	
36	1000012057	THM EBOX ASSY	1	



EPN-201606A

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWH-5.0NFWE

1	E04827	UPPER COVER	1	
2	E04963	SIDE COVER L UNIT	1	
3	E04964	SIDE COVER R UNIT	1	
4	E04830	BASE	1	
5	E04831	SERVICE COVER ASSY	1	
6	E04832	REAR COVER	1	
7	E04833	FILTER	1	
8	E04834	FILTER STAY	1	
9	E03800	MANOMETER	1	
11	E03273	COMPRESSOR H405DHD-64D1	1	
12	E04835	PLATE HEX	3	
14	E04837	PUMP	1	
15	E04838	HRN POWER PUMP ASSY	1	
16	E04839	HRN CONTROL PUMP ASSY	1	
17	E03798	Body	2	
18	E03271	3 WAY VALVE	1	
19	E04840	FILTER BALL	1	
19-1	E04841	FILTER	1	
19-2	E04842	SEEGER	1	
20	E04843	EXPANSION VESSEL	1	
21	E04844	P-SENSOR	1	
22	E04845	P-SENSOR	1	
23	E04860	HRN SV (COIL)	1	
24	E04861	HRN SV (COIL)	1	
25	E03078	EXPANSION VALVE	1	
26	P24654	EXP. VALVE	1	
27	E04847	PHEX SUPPORT L	1	
28	E04848	PHEX SUPPORT R	1	
29	E03769	ACOUSTICAL COVER 46	1	
30	E03180	EXPANSION VALVE COIL	1	
31	E03291	EXPV COIL	1	
32	E04849	VALVE PORT	1	
33	E04850	SECURITY VALVE	1	
34	E04851	THERMISTOR ASSY 1	1	
35	E04852	THERMISTOR ASSY 1	1	
36	E04853	THERMISTOR ASSY 2	1	
37	E04854	THERMISTOR ASSY 2	1	
38	E04855	THERMISTOR ASSY 3	1	
39	E04856	THERMISTOR ASSY 3	1	
40	E04857	PHEX INSULATION	1	
41	E04040	AIR PURGE	1	
42	P10777	Check Valve	2	
43	E03276	PRESSURE SWITCH	1	
44	P27887	PGC Joint	2	
45	E02532	Union	1	
46	E04858	HRN PRESSURE SWITCH	1	
47	E03805	Heater Harness	1	
48	E03806	Heater Harness	1	
49	E03807	Heater Harness	1	
50	E04859	UNION	1	

MODULE HYDRAULIQUE

RWH-5.0NFWE


51	E04846	SHUTDOWN VALVE	2	
52	E04824	GASKET	4	
53	E04862	VESSEL SUPPORT	1	
54	P26400	STRAINER	1	
55	E04069	MINI VALVE	1	
56	E04863	VALVE PORT	1	
57	E04864	VALVE PORT	1	
58	P25932	CHECK JOINT	2	
59	P25041	STRAINER	2	
60	E02488	UNION	1	
61	R4206	CHECK JOINT	3	
62	E02490	FLARE NUT	1	
63	E04865	FLARE NUT	1	
64	P17308	VIBRATION ABSORBER	4	
65	P13109	VIBRATION ABSORBER	4	
66	E04868	SEAL NUT	2	
67	E04869	FOOT	4	
68	E02487	UNION	1	
69	E02489	FLARE NUT	1	
70	P24397	Rubber Cap	1	
71	E02507	UNION	1	
72	P25037	STRAINER	1	
73	E02776	FLARE NUT	1	
74	E04871	SEAL GASKET	2	
75	E04872	VALVE PORT	1	
76	E02528	GASKET	4	
77	E03832	Gasket	2	
78	E02497	GASKET	2	
79	E04873	GASKET	1	
80	E02550	P-SPRING	1	
81	E02549	P-SPRING	1	
82	E02551	P-SPRING	4	
83	E02444	P-SPRING	1	

MODULE HYDRAULIQUE

RWH-5.0NFWE

Pièces détachées

Main view



EPN-201606A

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE


RWH-5.0NFWE

1	E04827	UPPER COVER	1	
2	E04963	SIDE COVER L UNIT	1	
3	E04964	SIDE COVER R UNIT	1	
4	E04830	BASE	1	
5	E04831	SERVICE COVER ASSY	1	
6	E04832	REAR COVER	1	
7	E04833	FILTER	1	
8	E04834	FILTER STAY	1	
9	E03800	MANOMETER	1	
11	E03273	COMPRESSOR H405DHD-64D1	1	
12	E04835	PLATE HEX	3	
14	E04837	PUMP	1	
15	E04838	HRN POWER PUMP ASSY	1	
16	E04839	HRN CONTROL PUMP ASSY	1	
17	E03798	Body	2	
18	E03271	3 WAY VALVE	1	
19	E04840	FILTER BALL	1	
19-1	E04841	FILTER	1	
19-2	E04842	SEEGER	1	
20	E04843	EXPANSION VESSEL	1	
21	E04844	P-SENSOR	1	
22	E04845	P-SENSOR	1	
23	E04860	HRN SV (COIL)	1	
24	E04861	HRN SV (COIL)	1	
25	E03078	EXPANSION VALVE	1	
26	P24654	EXP. VALVE	1	
27	E04847	PHEx SUPPORT L	1	
28	E04848	PHEx SUPPORT R	1	
29	E03769	ACOUSTICAL COVER 46	1	
30	E03180	EXPANSION VALVE COIL	1	
31	E03291	EXPV COIL	1	
32	E04849	VALVE PORT	1	
33	E04850	SECURITY VALVE	1	
34	E04851	THERMISTOR ASSY 1	1	
35	E04852	THERMISTOR ASSY 1	1	
36	E04853	THERMISTOR ASSY 2	1	
37	E04854	THERMISTOR ASSY 2	1	
38	E04855	THERMISTOR ASSY 3	1	
39	E04856	THERMISTOR ASSY 3	1	
40	E04857	PHEx INSULATION	1	
41	E04040	AIR PURGE	1	
42	P10777	Check Valve	2	
43	E03276	PRESSURE SWITCH	1	
44	P27887	PGC Joint	2	
45	E02532	Union	1	
46	E04858	HRN PRESSURE SWITCH	1	
47	E03805	Heater Harness	1	
48	E03806	Heater Harness	1	
49	E03807	Heater Harness	1	
50	E04859	UNION	1	

MODULE HYDRAULIQUE

RWH-5.0NFWE

51	E04846	SHUTDOWN VALVE	2	
52	E04824	GASKET	4	
53	E04862	VESSEL SUPPORT	1	
54	P26400	STRAINER	1	
55	E04069	MINI VALVE	1	
56	E04863	VALVE PORT	1	
57	E04864	VALVE PORT	1	
58	P25932	CHECK JOINT	2	
59	P25041	STRAINER	2	
60	E02488	UNION	1	
61	R4206	CHECK JOINT	3	
62	E02490	FLARE NUT	1	
63	E04865	FLARE NUT	1	
64	P17308	VIBRATION ABSORBER	4	
65	P13109	VIBRATION ABSORBER	4	
66	E04868	SEAL NUT	2	
67	E04869	FOOT	4	
68	E02487	UNION	1	
69	E02489	FLARE NUT	1	
70	P24397	Rubber Cap	1	
71	E02507	UNION	1	
72	P25037	STRAINER	1	
73	E02776	FLARE NUT	1	
74	E04871	SEAL GASKET	2	
75	E04872	VALVE PORT	1	
76	E02528	GASKET	4	
77	E03832	Gasket	2	
78	E02497	GASKET	2	
79	E04873	GASKET	1	
80	E02550	P-SPRING	1	
81	E02549	P-SPRING	1	
82	E02551	P-SPRING	4	
83	E02444	P-SPRING	1	



EPN-201606A

Rep.	Référence	Description	Qté	Remarques
------	-----------	-------------	-----	-----------

MODULE HYDRAULIQUE

RWH-5.0NFWE

1	E04827	UPPER COVER	1	
2	E04963	SIDE COVER L UNIT	1	
3	E04964	SIDE COVER R UNIT	1	
4	E04830	BASE	1	
5	E04831	SERVICE COVER ASSY	1	
6	E04832	REAR COVER	1	
7	E04833	FILTER	1	
8	E04834	FILTER STAY	1	
9	E03800	MANOMETER	1	
11	E03273	COMPRESSOR H405DHD-64D1	1	
12	E04835	PLATE HEX	3	
14	E04837	PUMP	1	
15	E04838	HRN POWER PUMP ASSY	1	
16	E04839	HRN CONTROL PUMP ASSY	1	
17	E03798	Body	2	
18	E03271	3 WAY VALVE	1	
19	E04840	FILTER BALL	1	
19-1	E04841	FILTER	1	
19-2	E04842	SEEGER	1	
20	E04843	EXPANSION VESSEL	1	
21	E04844	P-SENSOR	1	
22	E04845	P-SENSOR	1	
23	E04860	HRN SV (COIL)	1	
24	E04861	HRN SV (COIL)	1	
25	E03078	EXPANSION VALVE	1	
26	P24654	EXP. VALVE	1	
27	E04847	PHEX SUPPORT L	1	
28	E04848	PHEX SUPPORT R	1	
29	E03769	ACOUSTICAL COVER 46	1	
30	E03180	EXPANSION VALVE COIL	1	
31	E03291	EXPV COIL	1	
32	E04849	VALVE PORT	1	
33	E04850	SECURITY VALVE	1	
34	E04851	THERMISTOR ASSY 1	1	
35	E04852	THERMISTOR ASSY 1	1	
36	E04853	THERMISTOR ASSY 2	1	
37	E04854	THERMISTOR ASSY 2	1	
38	E04855	THERMISTOR ASSY 3	1	
39	E04856	THERMISTOR ASSY 3	1	
40	E04857	PHEX INSULATION	1	
41	E04040	AIR PURGE	1	
42	P10777	Check Valve	2	
43	E03276	PRESSURE SWITCH	1	
44	P27887	PGC Joint	2	
45	E02532	Union	1	
46	E04858	HRN PRESSURE SWITCH	1	
47	E03805	Heater Harness	1	
48	E03806	Heater Harness	1	
49	E03807	Heater Harness	1	
50	E04859	UNION	1	

MODULE HYDRAULIQUE

RWH-5.0NFWE

51	E04846	SHUTDOWN VALVE	2	
52	E04824	GASKET	4	
53	E04862	VESSEL SUPPORT	1	
54	P26400	STRAINER	1	
55	E04069	MINI VALVE	1	
56	E04863	VALVE PORT	1	
57	E04864	VALVE PORT	1	
58	P25932	CHECK JOINT	2	
59	P25041	STRAINER	2	
60	E02488	UNION	1	
61	R4206	CHECK JOINT	3	
62	E02490	FLARE NUT	1	
63	E04865	FLARE NUT	1	
64	P17308	VIBRATION ABSORBER	4	
65	P13109	VIBRATION ABSORBER	4	
66	E04868	SEAL NUT	2	
67	E04869	FOOT	4	
68	E02487	UNION	1	
69	E02489	FLARE NUT	1	
70	P24397	Rubber Cap	1	
71	E02507	UNION	1	
72	P25037	STRAINER	1	
73	E02776	FLARE NUT	1	
74	E04871	SEAL GASKET	2	
75	E04872	VALVE PORT	1	
76	E02528	GASKET	4	
77	E03832	Gasket	2	
78	E02497	GASKET	2	
79	E04873	GASKET	1	
80	E02550	P-SPRING	1	
81	E02549	P-SPRING	1	
82	E02551	P-SPRING	4	
83	E02444	P-SPRING	1	