


Pièces détachées

Main view



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-2.0NRWSE-260S-W

|      |        |                           |   |                                                                                     |
|------|--------|---------------------------|---|-------------------------------------------------------------------------------------|
| 1    | E04869 | FOOT                      | 4 |                                                                                     |
| 2    | E04968 | WATER TANK 260L SOLAR     | 1 |                                                                                     |
| 2-1  | E04088 | TANK HEATER               | 1 | (Tank Heater + Thermostat + O-Ring)                                                 |
| 2-1  | E06116 | O-Ring                    | 1 | (Only O-Ring for Tank Heater sealing)                                               |
| 2-2  | E04768 | BOTTOM TANK FLANGE        | 1 |                                                                                     |
| 3    | E04066 | FRONT INSULATION          | 1 |                                                                                     |
| 4    | E04067 | BACK INSULATION           | 1 |                                                                                     |
| 5    | E04068 | TH INSULATION             | 1 |                                                                                     |
| 6    | E04893 | EXPANSION VESSEL ( 6L )   | 1 |                                                                                     |
| 7    | E04048 | FLEXIBLE PIPE             | 1 | for Vessel connection.                                                              |
| 8    | E05007 | PHEX UNIT                 | 1 | Assembly.                                                                           |
| 8-1  | E04974 | INVALID COUNTRY OF ORIGIN | 1 |                                                                                     |
| 8-2  | E05942 | EXPANSION VALVE ASSY      | 1 | (Exp.Valve + Pipes + Strainers + Silencer)                                          |
| 8-2  | E03076 | EXPANSION VALVE           | 1 |                                                                                     |
| 8-3  | P25041 | STRAINER                  | 2 |  |
| 9    | E04073 | UNION                     | 2 |                                                                                     |
| 10   | E02488 | UNION                     | 1 | Gas connection.                                                                     |
| 11   | E02490 | FLARE NUT                 | 1 | Gas connection.                                                                     |
| 12   | E02935 | THE CAP                   | 1 | Liquid connection.                                                                  |
| 13   | E02936 | FLARE NUT                 | 1 | Liquid connection.                                                                  |
| 14   | E04894 | CIRCULATEUR               | 1 |                                                                                     |
| 15   | E06195 | E-Heater Unit             | 1 |                                                                                     |
| 16   | E03832 | Gasket                    | 8 | for Pump, E-Heater and Shutdown Valves connections.                                 |
| 17   | E04897 | FILTER BALL               | 1 |                                                                                     |
| 17-1 | E04898 | FILTER                    | 1 |                                                                                     |
| 17-2 | E04899 | SEEGER                    | 1 |                                                                                     |
| 18   | E02528 | GASKET                    | 7 | for FilterBall, 3-Way Valve and Tank Coil connections.                              |
| 19   | E03271 | 3 WAY VALVE               | 1 |                                                                                     |
| 20   | E04052 | GASKET                    | 2 | for Tank Water In/Out connections.                                                  |
| 21   | E02475 | SECURITY VALVE            | 1 |                                                                                     |
| 22   | E04873 | GASKET                    | 1 | for Union to Security Valve connection.                                             |
| 23   | E02507 | UNION                     | 1 |                                                                                     |
| 24   | E02546 | DRAIN PIPE                | 1 |                                                                                     |
| 25   | E04040 | AIR PURGE                 | 1 |                                                                                     |
| 26   | E06306 | PRESSURE SWITCH           | 1 |                                                                                     |
| 27   | E05017 | GASKET                    | 1 | for Pressure Switch connection.                                                     |
| 28   | E06197 | Lcd Support               | 1 |                                                                                     |
| 29   | E04960 | REMOTE CONTROL AS         | 1 |                                                                                     |
| 30   | E05014 | MANOMETER                 | 1 |                                                                                     |
| 31   | E05021 | E-BOX COVER ASSY          | 1 | Plate + Labels                                                                      |
| 32   | E02549 | P-SPRING                  | 1 |                                                                                     |
| 33   | E02550 | P-SPRING                  | 1 |                                                                                     |
| 34   | E01193 | P-SPRING                  | 3 |                                                                                     |
| 35   | E01897 | HANDLE                    | 2 |                                                                                     |
| 36   | E04069 | MINI VALVE                | 1 |                                                                                     |
| 37   | E02497 | GASKET                    | 3 | for Mini Valve, Seal Nut and Vessel connections.                                    |
| 38   | E05013 | UPPER COVER               | 1 |                                                                                     |
| 39   | E05012 | SERVICE COVER ASSY        | 1 | Assembly.                                                                           |

# MODULE HYDRAULIQUE

## RWD-2.0NRWSE-260S-W


|    |        |                           |   |                              |
|----|--------|---------------------------|---|------------------------------|
| 40 | E04955 | XEK12635 A - LCD FRAME    | 1 |                              |
| 41 | E04944 | XEK39388 A - YUTAKI FRAME | 1 |                              |
| 42 | E04954 | GASKET                    | 2 | for DHWT In/Out connections. |
| 43 | E05019 | SHUTDOWN VALVE            | 2 |                              |
| 44 | E04928 | THERMISTOR ASSY 1         | 1 | Water In THM.                |
| 45 | E04929 | THERMISTOR ASSY 1         | 1 | Water Out THM.               |
| 46 | E04981 | THERMISTOR ASSY 1         | 1 | Water Out PHEX THM.          |
| 47 | E04982 | THERMISTOR ASSY 2         | 1 | Gas THM.                     |
| 48 | E04983 | THERMISTOR ASSY 2         | 1 | Liquid THM.                  |
| 49 | E04965 | EXP. VALVE COIL           | 1 |                              |
| 50 | E05020 | THERMISTOR DHWT           | 1 | Tank surface.                |
| 51 | E04945 | XEK12635 A - LCD FRAME    | 2 |                              |
| 52 | E05026 | CLAMP                     | 1 |                              |
| 53 | E05027 | MANUAL AIR PURGE          | 1 |                              |
| 54 | E02501 | Screw                     | 4 |                              |
| 55 | E02060 | RUBBER BUSH               | 3 |                              |
| 58 | E05058 | SIDE COVER L              | 1 |                              |
| 59 | E05059 | SIDE COVER R              | 1 |                              |
| 60 | E06198 | Seal Nut                  | 1 |                              |

# MODULE HYDRAULIQUE

## RWD-2.0NRWSE-260S-W

Pièces détachées

Main view



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-2.0NRWSE-260S-W

|    |        |                      |    |                                                                                     |
|----|--------|----------------------|----|-------------------------------------------------------------------------------------|
| 1  | E04665 | INSTRUCTION ASSY PCB | 1  |  |
| 2  | E01789 | SPACER               | 12 |                                                                                     |
| 3  | E02519 | TERMINAL BOARD       | 1  |                                                                                     |
| 4  | E04778 | TERMINAL BOARD       | 1  |                                                                                     |
| 5  | E04779 | RELAY                | 3  |                                                                                     |
| 6  | E04780 | FUSE                 | 3  | 6,3A                                                                                |
| 8  | E04782 | FUSE                 | 1  | 20A                                                                                 |
| 9  | E04783 | HARNESS LIFTER       | 4  |                                                                                     |
| 10 | E04784 | ENDLING SADDLE       | 1  |                                                                                     |
| 11 | E02012 | CLAMP                | 1  |                                                                                     |
| 12 | E02060 | RUBBER BUSH          | 9  |                                                                                     |
| 13 | E04785 | THERMOSTAT           | 1  |                                                                                     |
| 14 | E06161 | ELECTRICAL BOX       | 1  | Assembly (Components +<br>Harness)                                                  |
| 16 | E04791 | E-BOX SUBASSY        | 1  | Only plate (without<br>components)                                                  |