


# MODULE HYDRAULIQUE

## RWD-6.0NWE-200S

Pièces détachées

Main view



| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-6.0NWE-200S

|      |        |                         |   |  |
|------|--------|-------------------------|---|--|
| 1    | E04869 | FOOT                    | 4 |  |
| 2    | E04966 | WATER TANK 200L         | 1 |  |
| 2-1  | E04088 | TANK HEATER             | 1 |  |
| 2-2  | E04768 | BOTTOM TANK FLANGE      | 1 |  |
| 3    | E04084 | FRONT INSULATION        | 1 |  |
| 4    | E04085 | BACK INSULATION         | 1 |  |
| 5    | E04068 | TH INSULATION           | 1 |  |
| 6    | E04893 | EXPANSION VESSEL ( 6L ) | 1 |  |
| 7    | E04048 | FLEXIBLE PIPE           | 1 |  |
| 8    | E05011 | PHEX UNIT               | 1 |  |
| 8-1  | E04835 | PLATE HEX               | 1 |  |
| 8-2  | E03078 | EXPANSION VALVE         | 1 |  |
| 8-3  | P25041 | STRAINER                | 2 |  |
| 9    | E04868 | SEAL NUT                | 2 |  |
| 10   | E04871 | SEAL GASKET             | 2 |  |
| 11   | E04073 | UNION                   | 1 |  |
| 12   | E02488 | UNION                   | 1 |  |
| 13   | E02490 | FLARE NUT               | 1 |  |
| 14   | E02487 | UNION                   | 1 |  |
| 15   | E02489 | FLARE NUT               | 1 |  |
| 16   | E04837 | PUMP                    | 1 |  |
| 17   | E05024 | E-HEATER UNIT           | 1 |  |
| 18   | E02496 | GASKET                  | 2 |  |
| 19   | E03832 | Gasket                  | 2 |  |
| 20   | E04840 | FILTER BALL             | 1 |  |
| 20-1 | E04841 | FILTER                  | 1 |  |
| 20-2 | E04842 | SEEGER                  | 1 |  |
| 21   | E02528 | GASKET                  | 7 |  |
| 22   | E03271 | 3 WAY VALVE             | 1 |  |
| 23   | E04052 | GASKET                  | 2 |  |
| 24   | E02475 | SECURITY VALVE          | 1 |  |
| 25   | E04873 | GASKET                  | 1 |  |
| 26   | E02507 | UNION                   | 1 |  |
| 27   | E02546 | DRAIN PIPE              | 1 |  |
| 28   | E04040 | AIR PURGE               | 1 |  |
| 29   | E02494 | PRESSURE SW             | 1 |  |
| 30   | E05017 | GASKET                  | 1 |  |
| 31   | E05006 | LCD SUPPORT             | 1 |  |
| 32   | E04960 | REMOTE CONTROL AS       | 1 |  |
| 33   | E05014 | MANOMETER               | 1 |  |
| 34   | E05021 | E-BOX COVER ASSY        | 1 |  |
| 35   | E02549 | P-SPRING                | 1 |  |
| 36   | E02550 | P-SPRING                | 1 |  |
| 37   | E02551 | P-SPRING                | 6 |  |
| 38   | E01897 | HANDLE                  | 2 |  |
| 39   | E04069 | MINI VALVE              | 2 |  |
| 40   | E02497 | GASKET                  | 3 |  |
| 41   | E05013 | UPPER COVER             | 1 |  |
| 42   | E05012 | SERVICE COVER ASSY      | 1 |  |
| 43   | E04955 | XEK12635 A - LCD FRAME  | 1 |  |

# MODULE HYDRAULIQUE

## RWD-6.0NWE-200S

|    |        |                           |   |  |
|----|--------|---------------------------|---|--|
| 44 | E04944 | XEK39388 A - YUTAKI FRAME | 1 |  |
| 45 | E04824 | GASKET                    | 4 |  |
| 46 | E04954 | GASKET                    | 2 |  |
| 47 | E04846 | SHUTDOWN VALVE            | 2 |  |
| 48 | E04928 | THERMISTOR ASSY 1         | 1 |  |
| 49 | E04980 | THERMISTOR ASSY 1         | 1 |  |
| 50 | E04981 | THERMISTOR ASSY 1         | 1 |  |
| 51 | E04982 | THERMISTOR ASSY 2         | 1 |  |
| 52 | E04983 | THERMISTOR ASSY 2         | 1 |  |
| 53 | E04965 | EXP. VALVE COIL           | 1 |  |
| 54 | E05020 | THERMISTOR DHWT           | 1 |  |
| 55 | E04945 | XEK12635 A - LCD FRAME    | 2 |  |
| 56 | E05026 | CLAMP                     | 1 |  |
| 57 | E05027 | MANUAL AIR PURGE          | 1 |  |
| 58 | E02501 | Screw                     | 4 |  |
| 59 | E02060 | RUBBER BUSH               | 3 |  |
| 62 | E05058 | SIDE COVER L              | 1 |  |
| 63 | E05059 | SIDE COVER R              | 1 |  |


# MODULE HYDRAULIQUE

## RWD-6.0NWE-200S

Pièces détachées

Main view

LOCATION OF SPARE PARTS IN THE UNIT  
ELECTRICAL EQUIPMENT



RWD-2.0NWE-200S(4)  
RWD-2.0NWE-200S(4)  
RWD-3.0NWE-200S(4)  
RWD-4.0NWE-200S(4)  
RWD-5.0NWE-200S(4)  
RWD-6.0NWE-200S(4)  
RWD-7.0NWE-200S(4)  
RWD-8.0NWE-200S(4)  
RWD-9.0NWE-200S(4)  
RWD-10.0NWE-200S(4)  
RWD-12.0NWE-200S(4)  
RWD-15.0NWE-200S(4)  
RWD-18.0NWE-200S(4)  
RWD-20.0NWE-200S(4)  
RWD-22.0NWE-200S(4)  
RWD-24.0NWE-200S(4)  
RWD-26.0NWE-200S(4)  
RWD-28.0NWE-200S(4)  
RWD-30.0NWE-200S(4)  
RWD-32.0NWE-200S(4)  
RWD-34.0NWE-200S(4)  
RWD-36.0NWE-200S(4)  
RWD-38.0NWE-200S(4)  
RWD-40.0NWE-200S(4)  
RWD-42.0NWE-200S(4)  
RWD-44.0NWE-200S(4)  
RWD-46.0NWE-200S(4)  
RWD-48.0NWE-200S(4)  
RWD-50.0NWE-200S(4)  
RWD-52.0NWE-200S(4)  
RWD-54.0NWE-200S(4)  
RWD-56.0NWE-200S(4)  
RWD-58.0NWE-200S(4)  
RWD-60.0NWE-200S(4)  
RWD-62.0NWE-200S(4)  
RWD-64.0NWE-200S(4)  
RWD-66.0NWE-200S(4)  
RWD-68.0NWE-200S(4)  
RWD-70.0NWE-200S(4)  
RWD-72.0NWE-200S(4)  
RWD-74.0NWE-200S(4)  
RWD-76.0NWE-200S(4)  
RWD-78.0NWE-200S(4)  
RWD-80.0NWE-200S(4)  
RWD-82.0NWE-200S(4)  
RWD-84.0NWE-200S(4)  
RWD-86.0NWE-200S(4)  
RWD-88.0NWE-200S(4)  
RWD-90.0NWE-200S(4)  
RWD-92.0NWE-200S(4)  
RWD-94.0NWE-200S(4)  
RWD-96.0NWE-200S(4)  
RWD-98.0NWE-200S(4)  
RWD-100.0NWE-200S(4)  
RWD-102.0NWE-200S(4)  
RWD-104.0NWE-200S(4)  
RWD-106.0NWE-200S(4)  
RWD-108.0NWE-200S(4)  
RWD-110.0NWE-200S(4)  
RWD-112.0NWE-200S(4)  
RWD-114.0NWE-200S(4)  
RWD-116.0NWE-200S(4)  
RWD-118.0NWE-200S(4)  
RWD-120.0NWE-200S(4)  
RWD-122.0NWE-200S(4)  
RWD-124.0NWE-200S(4)  
RWD-126.0NWE-200S(4)  
RWD-128.0NWE-200S(4)  
RWD-130.0NWE-200S(4)  
RWD-132.0NWE-200S(4)  
RWD-134.0NWE-200S(4)  
RWD-136.0NWE-200S(4)  
RWD-138.0NWE-200S(4)  
RWD-140.0NWE-200S(4)  
RWD-142.0NWE-200S(4)  
RWD-144.0NWE-200S(4)  
RWD-146.0NWE-200S(4)  
RWD-148.0NWE-200S(4)  
RWD-150.0NWE-200S(4)  
RWD-152.0NWE-200S(4)  
RWD-154.0NWE-200S(4)  
RWD-156.0NWE-200S(4)  
RWD-158.0NWE-200S(4)  
RWD-160.0NWE-200S(4)  
RWD-162.0NWE-200S(4)  
RWD-164.0NWE-200S(4)  
RWD-166.0NWE-200S(4)  
RWD-168.0NWE-200S(4)  
RWD-170.0NWE-200S(4)  
RWD-172.0NWE-200S(4)  
RWD-174.0NWE-200S(4)  
RWD-176.0NWE-200S(4)  
RWD-178.0NWE-200S(4)  
RWD-180.0NWE-200S(4)  
RWD-182.0NWE-200S(4)  
RWD-184.0NWE-200S(4)  
RWD-186.0NWE-200S(4)  
RWD-188.0NWE-200S(4)  
RWD-190.0NWE-200S(4)  
RWD-192.0NWE-200S(4)  
RWD-194.0NWE-200S(4)  
RWD-196.0NWE-200S(4)  
RWD-198.0NWE-200S(4)  
RWD-200.0NWE-200S(4)

EPN-201605A

| Rep. | Référence | Description | Qté | Remarques |
|------|-----------|-------------|-----|-----------|
|------|-----------|-------------|-----|-----------|

# MODULE HYDRAULIQUE

## RWD-6.0NWE-200S

|    |        |                      |    |                                                                                     |
|----|--------|----------------------|----|-------------------------------------------------------------------------------------|
| 1  | E04665 | INSTRUCTION ASSY PCB | 1  |  |
| 2  | E01789 | SPACER               | 12 |                                                                                     |
| 3  | E02519 | TERMINAL BOARD       | 1  |                                                                                     |
| 4  | E04778 | TERMINAL BOARD       | 1  |                                                                                     |
| 5  | E04779 | RELAY                | 3  |                                                                                     |
| 7  | E04781 | FUSE                 | 3  |                                                                                     |
| 8  | E04782 | FUSE                 | 1  |                                                                                     |
| 9  | E02516 | FUSE HOLDER          | 4  |                                                                                     |
| 10 | E03828 | Rocker Swith         | 1  |                                                                                     |
| 11 | E02012 | CLAMP                | 1  |                                                                                     |
| 12 | E02060 | RUBBER BUSH          | 9  |                                                                                     |
| 13 | E04785 | THERMOSTAT           | 1  |                                                                                     |
| 15 | E04787 | ELECTRICAL BOX       | 1  |                                                                                     |
| 16 | E04791 | E-BOX SUBASSY        | 1  |                                                                                     |