


CASSETTE

RCD-1.0FSN3

Pièces détachées

Main view

LOCATION OF SERVICE PARTS IN THE UNIT



Rep. Référence

Description

Qté Remarques

CASSETTE

RCD-1.0FSN3

1	P30483	FAN MOTOR	1
1-1	P30485	VIBRATION ABSORBER	3
2	P28899	Nut	3
3	P30486	TURBO FAN	1
4	P30487	NUT	1
5	P30488	DRAIN PUMP	1
6	P30489	FLOAT SWITCH ASSY	1
7	P30499	ANTIBACTERIAL AGENT ASSY	1
8	P21284	WIRE CLAMP	1
9	P29753	DRAIN HOSE ASSY	1
9-1	P21271	DRAIN HOSE	1
10	P30490	HEAT EXCHANGER ASSY	1
10-1	P28701	EXPANSION VALVE	1
10-2	P29142	Expv Motor	1
10-3	R4226	Flare Nut	1
11	P30500	WIND DIRECTION PLATE	2
12	17H25113 A	Pipe Cover Assy	1
13	P30494	Drain Pan Assy	1
13-1	17H26225 A	Hook	2
13-2	P28881	RUBBER PLUG	1
14	17G09328 A	M6 BOLT	4
15	P30496	BELL MOUTH ASSY	1
16	17F15064 B	Electrical Box Cover	1
17	P30501	THERMISTOR CASE	1
18	P24017	THERMISTOR	1
19	P23588	THERMISTOR	1
20	P28901	Thermistor	1
21	P28902	Thermistor	1
22	17H25097 A	Support Plate	1
23	P25911	HOSE	1
24	P28308	Clip	1
25	17F15063 B	Electrical Box	1
26	P30759	PCB-S	1
26-1	P27957	FUSE	1
27	P19516	SPACER	6
28	P30880	TERMINAL BLOCK	1
29	P30498	TERMINAL BLOCK	1